




YAMAHA

AG200F '97
3GX-AE1

SERVICE MANUAL





✓

✓



EB000000

AG200F
SERVICE MANUAL
©1997 by Yamaha Motor Co., Ltd.
1st Edition, January 1997
All rights reserved. Any reprinting or
unauthorized use without the written
permission of Yamaha Motor Co., Ltd.
is expressly prohibited.

HOW TO USE THIS MANUAL

MANUAL ORGANIZATION

This manual consists of chapters for the main categories of subjects. (See "Illustrated symbols")

- 1st title ①: This is the title of the chapter with its symbol on the upper right corner of each page.
- 2nd title ②: This title indicates the section of the chapter and only appears on the first page of each section. It is located in the upper left corner of the page.
- 3rd title ③: This title indicates a sub-section that is followed by step-by-step procedures accompanied by corresponding illustrations.

EXPLODED DIAGRAMS

To help identify parts and clarify procedure steps, there are exploded diagrams at start of each removal and disassembly section.

- 1. An easy-to-see exploded diagram ④ is provided for disassembly and assembly jobs.
- 2. Numbers ⑤ are given in the order of jobs in the exploded diagram. A number that is enclosed by a circle indicates a disassembly step.
- 3. An explanation of jobs and notes is presented in an easy-to-read way by the use of symbol marks ⑥. The meanings of the symbol marks are given on the next page.
- 4. A job instruction chart ⑦ accompanies the exploded diagram, providing the order of jobs, names of parts, notes in jobs, etc.
- 5. For jobs requiring more information, the step-by-step format supplements ⑧ are given in addition to the exploded diagram and the job instruction chart.

② CLUTCH

① ENG

④

③

CLUTCH

ENG

CLUTCH REMOVAL

1 Remove

- *Nut ① (clutch boss)
- *Lock washer ②
- *Clutch boss ③

Straighten the lock washer tab ④.

NOTE

Loosen the clutch boss nut ① while holding the clutch boss with a clutch holding tool ⑤.

Clutch holding tool
90890-04086

CLUTCH INSPECTION

1 Inspect

- *Friction plates
- Damage/wear → Replace the friction plates as a set

2 Measure

- *Friction plate thickness
- Out of specification → Replace the friction plates as a set
- Measure at four places

Thickness (friction plate)
2.9 - 3.1 mm
-Limit: 2.8 mm

3 Inspect

- *Clutch plates
- Damage → Replace the clutch plates as a set

4 Measure

- *Clutch plate warpage
- Out of specification → Replace the clutch plates as a set

























Use a surface plate and a feeler gauge ⑥.

Warp limit (clutch plate)
Less than 0.2 mm

5 inspect

- *Clutch springs
- Damage → Replace the clutch's springs as a set

Order	Job name/Part name	Qty	Remarks
	Clutch removal		Remove the parts in order
	Sprocket cover	4	Refer to "ENGINE REMOVAL" section
1	Clutch springs	4	
2	Pressure plate	1	Refer to "CLUTCH INSTALLATION" section
3	Nut/Washer	1/1	
4	Push plate	1	
5	Push rod #1/2 ring	1/1	
6	Clutch plates	4	
7	Friction plates	5	
8	Cush on spring	1	
9	Nut/Lock washer	1/1	Refer to "CLUTCH REMOVAL/INSTAL" section
10	Clutch boss	1	Refer to "CLUTCH REMOVAL/INSTAL" section
11	Plate washer	1	Refer to "CLUTCH INSTALLATION" section
12	Primary driven gear	1	

① GEN INFO 	② SPEC 
③ INSP ADJ 	④ ENG 
⑤ CARB 	⑥ CHAS 
⑦ ELEC 	⑧ TRBL SHTG 
⑨ 	⑩ 
⑪ 	⑫ 
⑬ 	⑭ 
⑮ 	⑯ 
⑰ 	⑱ 
⑲ 	
⑳ 	㉑ 
	㉒ 
㉓ 	㉔ 

EB003000

ILLUSTRATED SYMBOLS

Illustrated symbols ① to ⑨ are designed as thumb tabs to indicate the chapter's number and content.

- ① General information
- ② Specifications
- ③ Periodic inspection and adjustment
- ④ Engine
- ⑤ Carburation
- ⑥ Chassis
- ⑦ Electrical
- ⑧ Troubleshooting

Illustrated symbols ⑨ to ⑯ are used to identify the specifications appearing in the text.

- ⑨ Possible to maintain with engine mounted
- ⑩ Filling fluid
- ⑪ Lubricant
- ⑫ Special tool
- ⑬ Tightening
- ⑭ Wear limit, clearance
- ⑮ Engine speed
- ⑯ Ω, V, A








Illustrated symbols ⑰ to ㉒ in the exploded diagrams indicate the types of lubricants and lubrication points.

- ⑰ Apply engine oil
- ⑱ Apply gear oil
- ⑲ Apply molybdenum disulfide oil
- ⑳ Apply wheel bearing grease
- ㉑ Apply lightweight lithium-soap base grease
- ㉒ Apply molybdenum disulfide grease

Illustrated symbols ㉓ to ㉔ in the exploded diagrams indicate the where to apply locking agent ㉓ and when to install new parts ㉔.

- ㉓ Apply locking agent (LOCTITE®)
- ㉔ Use new one

INDEX

GENERAL INFORMATION	
	GEN INFO 1
SPECIFICATIONS	
	SPEC 2
PERIODIC INSPECTION AND ADJUSTMENT	
	INSP ADJ 3
ENGINE OVERHAUL	
	ENG 4
CARBURATION	
	CARB 5
CHASSIS	
	CHAS 6
ELECTRICAL	
	ELEC 7
TROUBLESHOOTING	?
	TRBL SHTG 8

CHAPTER 1. GENERAL INFORMATION

MOTORCYCLE IDENTIFICATION	1-1
FRAME SERIAL NUMBER.....	1-1
MODEL LABEL.....	1-1
IMPORTANT INFORMATION	1-2
PREPARATION FOR REMOVAL PROCEDURES.....	1-2
REPLACEMENT PARTS.....	1-2
GASKETS, OIL SEALS AND O-RINGS.....	1-2
LOCK WASHERS/PLATES AND COTTER PINS.....	1-3
BEARINGS AND OIL SEALS.....	1-3
CIRCLIPS.....	1-3
CHECKING OF CONNECTIONS	1-4
HOW TO USE THE CONVERSION TABLE	1-5
SPECIAL TOOLS	1-6

CHAPTER 2. SPECIFICATIONS

GENERAL SPECIFICATIONS	2-1
MAINTENANCE SPECIFICATIONS	2-4
ENGINE.....	2-4
CHASSIS.....	2-10
ELECTRICAL.....	2-13
GENERAL TORQUE SPECIFICATIONS	2-15
LUBRICATION POINT AND GRADE OF LUBRICANT	2-16
ENGINE.....	2-16
CHASSIS.....	2-17
LUBRICATION DIAGRAM	2-18
CABLE ROUTING	2-20

CHAPTER 3. PERIODIC INSPECTIONS AND ADJUSTMENTS

INTRODUCTION	3-1
PERIODIC MAINTENANCE/LUBRICATION INTERVALS	3-1
SIDE COVER, SEAT AND FUEL TANK	3-3
ENGINE	3-4
VALVE CLEARANCE ADJUSTMENT.....	3-4
IDLING SPEED ADJUSTMENT.....	3-5
THROTTLE CABLE ADJUSTMENT.....	3-6
SPARK PLUG INSPECTION.....	3-7
IGNITION TIMING CHECK.....	3-8
COMPRESSION PRESSURE MEASUREMENT.....	3-9
ENGINE OIL LEVEL INSPECTION.....	3-10
ENGINE OIL REPLACEMENT.....	3-11



CLUTCH ADJUSTMENT.....	3-13
AIR FILTER CLEANING	3-14
EXHAUST SYSTEM INSPECTION	3-15
CHASSIS	3-16
FRONT BRAKE ADJUSTMENT	3-16
REAR BRAKE ADJUSTMENT.....	3-16
BRAKE SHOE INSPECTION.....	3-18
BRAKE LIGHT SWITCH ADJUSTMENT	3-18
DRIVE CHAIN SLACK ADJUSTMENT	3-18
STEERING HEAD INSPECTION.....	3-21
FRONT FORK INSPECTION.....	3-22
REAR SHOCK ABSORBER ADJUSTMENT	3-22
TIRE INSPECTION.....	3-23
SPOKE INSPECTION AND TIGHTENING	3-25
WHEEL INSPECTION	3-25
ELECTRICAL	3-26
BATTERY INSPECTION.....	3-26
FUSE INSPECTION	3-31
HEADLIGHT BEAM ADJUSTMENT.....	3-32

CHAPTER 4. ENGINE OVERHAUL

ENGINE REMOVAL	4-1
EXHAUST PIPE, STARTING MOTOR AND WIRE READ.....	4-1
CARBURETOR, CLUTCH CABLE AND DRIVE CHAIN.....	4-2
ENGINE.....	4-3
CYLINDER HEAD	4-4
CAM SPROCKET COVER.....	4-4
CYLINDER HEAD.....	4-5
CYLINDER HEAD REMOVAL	4-6
CYLINDER HEAD INSPECTION.....	4-7
TIMING CHAIN TENSIONER ADJUSTMENT	4-7
CYLINDER HEAD INSTALLATION	4-8
CAM SHAFT AND ROCKER ARMS	4-10
ROCKER ARM AND ROCKER ARM SHAFT REMOVAL	4-11
CAMSHAFT INSPECTION	4-11
ROCKER ARMS AND ROCKER ARM SHAFTS INSPECTION	4-12
CAMSHAFT AND ROCKER ARM INSTALLATION	4-12
VALVES AND VALVE SPRINGS	4-14
VALVES AND VALVE SPRINGS REMOVAL.....	4-15
VALVES AND VALVE GUIDES INSPECTION	4-15
VALVE SEATS INSPECTION	4-17
VALVES AND VALVE SPRINGS INSTALLATION	4-18
CYLINDER AND PISTON	4-20
PISTON AND PISTON RINGS REMOVAL.....	4-21
CYLINDER AND PISTON INSPECTION	4-21
PISTON RING INSPECTION	4-23
PISTON PIN INSPECTION	4-24

PISTON RINGS, PISTON AND CYLINDER INSTALLATION.....	4-24
CLUTCH	4-26
CRANKCASE COVER (RIGHT).....	4-26
CLUTCH.....	4-27
CLUTCH REMOVAL.....	4-29
CLUTCH INSPECTION.....	4-29
PUSH ROD INSPECTION.....	4-30
CLUTCH INSTALLATION.....	4-30
KICK STARTER	4-34
KICK STARTER INSPECTION.....	4-34
KICK STARTER INSTALLATION.....	4-34
OIL PUMP	4-35
PRIMARY DRIVE GEAR REMOVAL.....	4-37
OIL PUMP INSPECTION.....	4-37
OIL DELIVERY PASSAGE INSPECTION (CRANK CASE COVER (right)).....	4-37
OIL PUMP INSTALLATION.....	4-38
PRIMARY DRIVE GEAR INSTALLATION.....	4-38
BALANCER GEAR	4-39
BALANCER DRIVEN GEAR REMOVAL.....	4-40
BALANCER DRIVE GEAR INSPECTION.....	4-40
BALANCER DRIVE GEAR ASSEMBLY.....	4-40
BALANCER GEAR INSTALLATION.....	4-41
SHIFT SHAFT AND SEGMENT	4-42
SHIFT SHAFT REMOVAL.....	4-44
SHIFT SHAFT INSPECTION.....	4-44
SEGMENT INSTALLATION.....	4-44
SHIFT SHAFT INSTALLATION.....	4-45
CDI MAGNETO AND STARTER CLUTCH	4-46
CRANKCASE COVER (LEFT).....	4-46
PICKUP COIL AND STATOR COIL.....	4-47
CDI MAGNETO AND STARTER CLUTCH.....	4-48
CDI MAGNETO REMOVAL.....	4-49
STARTER CLUTCH INSPECTION.....	4-49
STARTER CLUTCH INSTALLATION.....	4-50
CDI MAGNETO INSTALLATION.....	4-50
CRANK CASE AND CRANKSHAFT	4-52
CRANKCASE.....	4-52
CRANKSHAFT AND BALANCER WEIGHT.....	4-54
CRANKCASE SEPARATION.....	4-55
PLUNGER SEAL REMOVAL.....	4-55
CRANKSHAFT INSPECTION.....	4-56
PLUNGER SEAL INSTALLATION.....	4-57
BALANCER WEIGHT INSTALLATION.....	4-57
CRANKCASE INSTALLATION.....	4-57
TRANSMISSION, SHIFT CAM AND SHIFT FORK	4-58
TRANSMISSION, SHIFT CAM AND SHIFT FORK REMOVAL.....	4-60
SHIFT FORK AND SHIFT CAM INSPECTION.....	4-60
TRANSMISSION, SHIFT CAM AND SHIFT FORK INSTALLATION.....	4-61



CHAPTER 5. CARBURETION

CARBURETOR	5-1
CARBURETOR ASSEMBLY	5-4
FUEL LEVEL ADJUSTMENT	5-5

CHAPTER 6. CHASSIS

FRONT WHEEL AND FRONT BRAKE	6-1
FRONT WHEEL DISASSEMBLY	6-4
BRAKE SHOE PLATE DISASSEMBLY	6-4
FRONT WHEEL INSPECTION	6-4
SPEEDOMETER GEAR INSPECTION	6-5
FRONT BRAKE INSPECTION	6-6
FRONT SHOE PLATE ASSEMBLY	6-7
FRONT WHEEL ASSEMBLY	6-8
FRONT WHEEL INSTALLATION	6-8
WHEEL STATIC BALANCE ADJUSTMENT	6-10
REAR WHEEL, REAR BRAKE AND DRIVE CHAIN	6-12
REAR WHEEL AND REAR BRAKE	6-12
DRIVE CHAIN, DRIVE SPROCKET AND DRIVEN SPROCKET	6-16
REAR WHEEL DISASSEMBLY	6-19
REAR WHEEL INSPECTION	6-19
REAR BRAKE INSPECTION	6-19
DRIVE CHAIN INSPECTION	6-20
CLUTCH HUB INSPECTION	6-21
BRAKE SHOE PLATE ASSEMBLY	6-21
REAR WHEEL ASSEMBLY	6-21
DRIVEN SPROCKET ASSEMBLY	6-22
DRIVEN SPROCKET AND DRIVE CHAIN INSTALLATION	6-22
REAR WHEEL INSTALLATION	6-23
FRONT FORK	6-24
FRONT FORK REMOVAL	6-26
FRONT FORK DISASSEMBLY	6-26
FRONT FORK INSPECTION	6-27
FRONT FORK ASSEMBLY	6-28
FRONT FORK INSTALLATION	6-30
HANDLEBAR	6-31
HANDLEBAR REMOVAL	6-33
HANDLEBAR INSPECTION	6-33
HANDLEBAR INSTALLATION	6-33
STEERING	6-35
UNDER BRACKET	6-35
STEERING REMOVAL	6-37
STEERING INSPECTION	6-37
STEERING INSTALLATION	6-38
REAR SHOCK ABSORBER AND SWINGARM	6-39


SWINGARM INSPECTION	6-41
SWINGARM SIDE CLEARANCE ADJUSTMENT	6-41
REAR SHOCK ABSORBER HANDLING NOTES.....	6-42
NOTES ON DISPOSAL	6-42

CHAPTER 7. ELECTRICAL

ELECTRICAL COMPONENTS	7-1
SWITCH INSPECTION	7-2
INSPECTION STEPS	7-2
SWITCH CONNECTION AS SHOWN IN THIS MANUAL.....	7-2
SWITCH CONTINUITY INSPECTION	7-3
IGNITION SYSTEM	7-4
CIRCUIT DIAGRAM.....	7-4
TROUBLESHOOTING	7-5
ELECTRIC STARTING SYSTEM	7-10
CIRCUIT DIAGRAM.....	7-10
STARTING CIRCUIT OPERATION	7-11
TROUBLESHOOTING	7-12
STARTER MOTOR.....	7-16
CHARGING SYSTEM	7-20
CIRCUIT DIAGRAM.....	7-20
TROUBLESHOOTING	7-21
LIGHTING SYSTEM	7-24
CIRCUIT DIAGRAM.....	7-24
TROUBLESHOOTING	7-25
LIGHTING SYSTEM CHECK	7-26
AUXILIARY DC OUTPUT SYSTEM CHECK	7-28
SIGNAL SYSTEM	7-29
CIRCUIT DIAGRAM.....	7-29
TROUBLESHOOTING	7-30
SIGNAL SYSTEM CHECK.....	7-32

CHAPTER 8. TROUBLE SHOOTING

STARTING FAILURE/HARD STARING	8-1
POOR IDLE SPEED PERFORMANCE	8-2
POOR MEDIUM AND HIGH SPEED PERFORMANCE	8-3
POOR SPEED PERFORMANCE	8-3
CLUTCH SLIPPING/Dragging	8-4
FAULTY GEAR SHIFTING	8-4
OVER HEATING OR OVER-COOLING	8-5
FAULTY BRAKE	8-5
FRONT FORK MALFUNCTION	8-6
INSTABLE HANDLING	8-6
STARTER MOTOR DOES NOT OPERATE	8-7
FAULTY SIGNAL AND LIGHTING SYSTEM	8-8




YP100000

GENERAL INFORMATION MOTORCYCLE IDENTIFICATION

SR100020




FRAME SERIAL NUMBER

The frame serial number ① is stamped into the right side of the frame



MODEL LABEL

The model label ① is affixed under the fuel tank. This information will be needed to order spare parts.



EB101000

IMPORTANT INFORMATION**PREPARATION FOR REMOVAL PROCEDURES**

1. Remove all dirt, mud, dust and foreign material before removal and disassembly.
2. Use proper tools and cleaning equipment.
3. Refer to the "SPECIAL TOOLS" section.
4. When disassembling the machine, always keep mated parts together. This includes gears, cylinders, pistons and other parts that have been "mated" through normal wear. Mated parts must always be reused or replaced as an assembly.
5. During machine disassembly, clean all parts and place them in trays in the order of disassembly. This will speed up assembly and allow for the correct installation of all parts.
6. Keep all parts away from any source of fire.

EB101010


REPLACEMENT PARTS

1. Use only genuine Yamaha parts for all replacements. Use oil and grease recommended by Yamaha for all lubrication jobs. Other brands may be similar in function and appearance, but inferior in quality.

EB101020

GASKETS, OIL SEALS AND O-RINGS


1. Replace all gaskets, seals and O-rings when overhauling the engine. All gasket surfaces, oil seal lips and O-rings must be cleaned.
2. Properly oil all mating parts and bearings during reassembly. Apply grease to the oil seal lips.



EB101030

LOCK WASHERS/PLATES AND COTTER PINS

1. Replace all lock washers/plates and cotter pins after removal. Bend lock tabs along the bolt or nut flats after the bolt or nut has been tightened to specification.




EB101040

BEARINGS AND OIL SEALS

Install bearings and oil seals so that the manufacturer's marks or numbers are visible. When installing oil seals, apply a light coating of lightweight lithium base grease to the seal lips. Oil bearings liberally when installing, if appropriate.


- ① Oil seal



CAUTION:

Do not use compressed air to spin the bearings dry. This will damage the bearing surfaces.

- ① Bearing







EB101050

CIRCLIPS

1. Check all circlips carefully before reassembly. Always replace piston pin clips after one use. Replace distorted circlips. When installing a circlip ①, make sure that the sharp-edged corner ② is positioned opposite the thrust ③ it receives. See sectional view.

- ④ Shaft



EB801000

CHECKING OF CONNECTIONS

Dealing with stains, rust, moisture, etc. on the connector.

1. Disconnect:
 - Connector
2. Dry each terminal with an air blower.

3. Connect and disconnect the connector two or three.
4. Pull the lead to check that it will not come off.
5. If the terminal comes off, bend up the pin ① and reinsert the terminal into the connector.

6. Connect:
 - Connector

NOTE: _____


The two connectors "click" together.

7. Check for continuity with a tester.

NOTE: _____

- If there is no continuity, clean the terminals.
- Be sure to perform the steps 1 to 7 listed above when checking the wireharness.
- For a field remedy, use a contact revitalizer available on the market.
- Use the tester on the connector as shown.

HOW TO USE THE CONVERSION TABLE



EB201000

HOW TO USE THE CONVERSION TABLE

All specification data in this manual are listed in SI and METRIC UNITS.

Use this table to convert METRIC unit data to IMPERIAL unit data.

Ex.

METRIC		MULTIPLIER		IMP
** mm	×	0.03937	=	** in
2 mm	×	0.03937	=	0.08 in

CONVERSION TABLE

METRIC TO IMP			
	Known	Multiplier	Result
Torque	m•kg	7.233	ft•lb
	m•kg	86.794	in•lb
	cm•kg	0.0723	ft•lb
	cm•kg	0.8679	in•lb
Weight	kg	2.205	lb
	g	0.03527	oz
Distance	km/hr	0.6214	mph
	km	0.6214	mi
	m	3.281	ft
	m	1.094	yd
	cm	0.3937	in
	mm	0.03937	in
Volume/ Capacity	cc (cm ³)	0.03527	oz (IMP liq.)
	cc (cm ³)	0.06102	cu•in
	lit (liter)	0.8799	qt (IMP liq.)
	lit (liter)	0.2199	gal (IMP liq.)
Miscellaneous	kg/mm	55.997	lb/in
	kg/cm ²	14.2234	psi (lb/in ²)
	Centigrade	9/5(°C)+32	Fahrenheit (°F)



EB102000











SPECIAL TOOLS

The following special tools are necessary for complete and accurate tune-up and assembly. Use only the appropriate special tools; this will help prevent damage caused by the use of inappropriate tools or improvised techniques.






When placing an order, refer to the list provided below to avoid any mistakes.


Tool No.	Tool name / Usage	Illustration
90890-01052	Meter gear bush tool This tool is used when removing or installing the meter gear bush.	
90890-01080 -04052	Rotor puller Attachment These tools are used when removing the magneto rotor.	
90890-01083 -01084	Rocker arm shaft puller bolt Weight These tools are used when removing or installing the rocker arm shafts.	
90890-01268	Ringnut wrench This tool is used to loosen and tighten the exhaust and steering ringnut.	
90890-01311	Valve adjusting tool This tool is necessary for adjusting valve clearance.	
90890-01312	Fuel level gauge This gauge is used to measure the fuel level in the float chamber.	
90890-01326 -04084	T-handle Damper rod holder (19 mm) These tools are used to loosen and tighten the front fork damper rod holding bolt.	
90890-01367 -01369	Fork seal driver weight Fork seal driver attachment (ø35 mm) These tools are used when installing the fork seal.	
90890-01403	Ring nut wrench This tool is used to loosen and tighten the steering ring nut.	



Tool No.	Tool name / Usage	Illustration
90890-01701	<p>Sheave holder</p> <p>This tool is used for holding the magneto rotor.</p>	
90890-03079	<p>Thickness gauge</p> <p>This tool is used to measure the valve clearance.</p>	
90890-03081 -04082	<p>Compression gauge Adaptor</p> <p>These tools are used to measure the engine compression.</p>	
90890-03112	<p>Pocket tester</p> <p>This instrument is invaluable for checking the electrical system.</p>	
90890-03113	<p>Engine tachometer</p> <p>This tool is needed for detecting engine rpm</p>	
90890-03141	<p>Timing light</p> <p>This tool is needed for detecting engine rpm.</p>	
90890-04019 -04108	<p>Valve spring compressor Attachment</p> <p>These tools are used when removing or installing the valve and the valve spring.</p>	
90890-04064	<p>Valve guide remover 6mm</p> <p>This tool is used to remove the valve guide.</p>	
90890-04065	<p>Valve guide reamer 6mm</p> <p>This tool is used to rebore the valve guide.</p>	
90890-04066	<p>Valve guide installer 6mm</p> <p>This tool is needed to install the valve guides properly.</p>	



Tool No.	Tool name / Usage	Illustration
90890-04086	Clutch holding tool This tool is used for holding the Clutch Boss.	
90890-04101	Valve lapper This tool is used for removing and installing the lifter and for lapping the valve.	
90890-05245	Torques wrench This tool is used for removing and installing the segment bolt.	
90890-06754	Ignition checker This instrument is necessary for checking the ignition system components.	
90890-85505	Yamaha bond No. 1215 This sealant (bond) is used for crankcase mating surface, etc.	



SPECIFICATIONS

GENERAL SPECIFICATIONS

Model	AG200F
Model code:	3GXA
Dimensions:	
Overall length	2,160 mm
Overall width	930 mm
Overall height	1,155 mm
Seat height	830 mm
Wheelbase	1,345 mm
Minimum ground clearance	255 mm
Minimum turning radius	2,000 mm
Basic weight:	
With oil and full fuel tank	127 kg
Engine:	
Engine type	Air-cooled 4-stroke, SOHC
Cylinder arrangement	Forward-inclined single cylinder
Displacement	0.196 L (196 cm ³)
Bore × stroke	67.0 × 55.7 mm
Compression ratio	9.5 : 1
Compression pressure (STD)	900 kPa (9.0 kg/cm ² , 9.0 bar) at 1,000 r/min
Starting system	Electric starter
Lubrication system:	Wet sump
Oil type or grade:	
Engine oil	API "SE" or higher grade
<p>The chart shows temperature ranges in Celsius (°C) and Fahrenheit (°F) for four oil grades:</p> <ul style="list-style-type: none"> 10W/30: -20°C to 30°C 10W/40: -10°C to 40°C 20W/40: 0°C to 40°C 20W/50: 0°C to 40°C 	
Periodic oil change	1.0 L
With oil filter replacement	1.1 L
Total amount	1.3 L
Air filter:	Wet type element
Fuel:	
Type	Regular unleaded gasoline
Fuel tank capacity	10.0 L
Fuel reserve capacity	2.0 L



Model	AG200F
Carburetor: Type/quantity Manufacturer	BS26/1 MIKUMI
Spark plug: Type Manufacturer Spark plug gap	D8EA/X24ES-U NGK/DENSO 0.6~0.7 mm
Clutch type:	Wet, multiple - disc
Transmission: Primary reduction system Primary reduction ratio Secondary reduction system Secondary reduction ratio Transmission type Operation Gear ratio 1st 2nd 3rd 4th 5th	Spur gear 74/20 (3.700) Chain drive 54/14 (3.857) Constant mesh 5 speed Left foot operation 35/11 (3.181) 31/15 (2.066) 30/21 (1.428) 25/26 (0.961) 22/31 (0.709)
Chassis: Frame type Caster angle Trail	Diamond 27.9° 87 mm
Tire: Type Size front rear Manufacturer front rear Type front rear	Tube type 80/100-21 51M 4.00-18 59M INOUE INOUE VE-32 FARM SPECIAL - Z2
Tire pressure (cold tire): Maximum load-except motorcycle Loading condition A * front rear	112 kg 0~112 kg 120 kPa (1.2 kg/cm ² , 1.2 bar) 150 kPa (1.5 kg/cm ² , 1.5 bar)

*Load is the total weight of cargo, rider, passenger, and accessories.

GENERAL SPECIFICATIONS

SPEC






Model	AG200F
Brake: Front brake type operation Rear brake type operation	Drum brake Right hand operation Drum brake Right foot operation
Suspension: Front suspension Rear suspension	Telescopic fork Swingarm (monocross)
Shock absorber: Front shock absorber Rear shock absorber	Coil spring/Oil damper Coil spring/Gas-Oil damper
Wheel travel: Front wheel travel Rear wheel travel	200 mm 165 mm
Electrical: Ignition system Generator system Battery type Battery capacity	CDI CDI magneto GT6B-3 12V 6 AH
Headlight type:	Bulb type
Bulb wattage × quantity: Headlight Tail/brake light Flasher light Meter light Neutral indicator	12V 45 W/45 W × 1 12V 5 W/21 W × 1 12V 10 W × 4 12V 1.7 W × 1 12V 1.7 W × 1



MAINTENANCE SPECIFICATIONS

ENGINE


Item	Standard	Limit
Cylinder head: Warp limit	...	0.03 mm
Cylinder: Bore size Measuring point*	 66.97~67.02 mm 40 mm	67.1 mm ...
Camshaft: Cam dimensions Intake "A" "B" "C" Exhaust "A" "B" "C" Camshaft runout limit	 36.54~36.64 mm 30.15~30.25 mm 6.59 mm 36.58~36.68 mm 30.27~30.37 mm 6.63 mm ...	36.48 mm 30.1mm ... 36.49 mm 30.2 mm ... 0.03 mm
Cam chain: Cam chain type/No. of links Cam chain adjustment	DID 25SH/104 ENDLESS Automatic
Rocker arm/rocker armshaft: Rocker arm inside diameter Rocker shaft outside diameter Rocker arm-to-rocker armshaft clearance	12.000~12.018 mm 11.981~11.991 mm 0.009~0.037 mm	12.036 mm 11.950 mm ...
Valve, valve seat, valve guide: Valve clearance (cold) Valve dimensions	IN 0.10~0.14 mm EX 0.16~0.20 mm 
"A" head diameter	IN 33.9~234.1 mm EX 28.4~28.6 mm
"B" face width	IN 2.26 mm EX 2.26 mm
"C" seat width	IN 0.9~1.1 mm EX 0.9~1.1 mm	1.6 mm 1.6 mm
"D" margin thickness	IN 0.8~1.2 mm EX 0.8~1.2 mm
Stem outside diameter	IN 5.975~5.990 mm EX 5.960~5.975 mm	5.955 mm 5.940 mm

MAINTENANCE SPECIFICATIONS

SPEC




Item		Standard	Limit
Guide inside diameter	IN	6.000~6.012 mm	6.042 mm
	EX	6.000~6.012 mm	6.042 mm
Stem-to-guide clearance	IN	0.010~0.037 mm	0.08 mm
	EX	0.025~0.052 mm	0.10 mm
Stem runout limit		...	0.03 mm
Valve seat width	IN	0.9~1.1 mm	1.6 mm
	EX	0.9~1.1 mm	1.6 mm
Valve spring:			
Free length (inner)	IN/EX	35.5 mm	33.5 mm
	IN/EX	37.2 mm	35.2 mm
Set length (valve closed)	IN/EX	30.5 mm	...
	IN/EX	32.0 mm	...
Compressed pressure	IN/EX	8.4~10.2 kg	...
	IN/EX	16.6~20.4 kg	...
Tilt limit (inner)	IN/EX	...	2.5°/1.5 mm
Tilt limit (outer)	IN/EX	...	2.5°/1.6 mm
Direction of winding	(inner) IN/EX	Counterclockwise	...
	(outer) IN/EX	Clockwise	...
Piston:			
Piston to cylinder clearance		0.025~0.045 mm	...
Piston size "D"		66.935~66.985 mm	...
Measuring point "H"		7.5 mm	...
Piston over size (1st)		67.25 mm	...
Piston over size (2nd)		67.50 mm	...
Piston pin bore inside diameter		16.002~16.013 mm	...
Piston pin outside diameter		15.991~16.000 mm	...
Piston pin to piston clearance		0.002~0.022 mm	...
Piston rings:			
Top ring:			
Type		Barrel	...
Dimensions (B × T)		1.2 × 2.7 mm	...
End gap (installed)		0.15~0.35 mm	0.60 mm
Side clearance (installed)		0.03~0.07 mm	0.15 mm
2nd ring:			
Type		Taper	...
Dimensions (B × T)		1.2 × 2.7 mm	...
End gap (installed)		0.15~0.35 mm	0.60 mm
Side clearance		0.02~0.06 mm	0.15 mm
Oil ring:			
Dimensions (B × T)		2.5 × 2.8 mm	...
End gap (installed)		0.3~0.9 mm	...



MAINTENANCE SPECIFICATIONS

SPEC



Item	Standard	Limit
<p>Crankshaft:</p> <div style="display: flex; align-items: center;">  <div> <p>Crank width "A"</p> <p>Runout limit "C"</p> <p>Big end side clearance "D"</p> <p>Big end radial clearance</p> <p>Small end free play "F"</p> </div> </div>	<p>55.95~56.00 mm</p> <p>...</p> <p>0.35~0.65 mm</p> <p>0.010~0.025 mm</p> <p>0.8~1.0 mm</p>	<p>...</p> <p>0.03 mm</p> <p>1.0 mm</p> <p>...</p> <p>...</p>
<p>Clutch:</p> <p>Friction plate thickness</p> <p>Quantity</p> <p>Clutch plate thickness</p> <p>Quantity</p> <p>Clutch spring free length</p> <p>Quantity</p> <p>Push rod bending limit</p>	<p>2.9~3.1 mm</p> <p>5 pcs.</p> <p>1.5~1.7 mm</p> <p>4 pcs.</p> <p>37.3 mm</p> <p>4 pcs.</p> <p>...</p>	<p>2.8 mm</p> <p>...</p> <p>0.2 mm</p> <p>...</p> <p>35.3 mm</p> <p>...</p> <p>0.5 mm</p>
<p>Transmission:</p> <p>Main axle runout limit</p> <p>Drive axle runout limit</p>	<p>...</p> <p>...</p>	<p>0.08 mm</p> <p>0.08 mm</p>
<p>Carburetor:</p> <p>Type</p> <p>I.D. mark</p> <p>Main jet (M.J)</p> <p>Main air jet (M.A.J)</p> <p>Jet needle (J.N)</p> <p>Needle jet (N.J)</p> <p>Pilot outlet (P.O)</p> <p>Pilot jet (P.J)</p> <p>Pilot air jet (P.A.J)</p> <p>Bypass 1 (B.P.1)</p> <p>Bypass 2 (B.P.2)</p> <p>Bypass 3 (B.P.3)</p> <p>Pilot screw (P.S)</p> <p>Valve seat size (V.S)</p> <p>Starter jet 1 (G.S.1)</p> <p>Starter jet 2 (G.S.2)</p> <p>Throttle valve size (TH. V)</p> <p>Fuel level (F.L)</p> <p>(with special tool)</p> <p>Engine idle speed</p> <p>Intake vacuum</p>	<p>BS26</p> <p>36X 01</p> <p>#117.5</p> <p>ϕ1.6</p> <p>4FP40-4</p> <p>P-2</p> <p>0.8</p> <p>#35</p> <p>#125</p> <p>0.8</p> <p>0.8</p> <p>0.8</p> <p>2</p> <p>ϕ2.0</p> <p>#30</p> <p>0.5</p> <p>#120</p> <p>2.5 ~ 3.5 mm</p> <p>1,300~1,400 r/min</p> <p>180~200 mmHg</p>	<p>...</p> <p>...</p> <p>...</p> <p>...</p> <p>...</p> <p>...</p> <p>...</p> <p>...</p> <p>...</p> <p>...</p> <p>...</p> <p>...</p> <p>...</p> <p>...</p> <p>...</p> <p>...</p> <p>...</p> <p>...</p> <p>...</p> <p>...</p> <p>...</p> <p>...</p>
<p>Oil pump:</p> <p>Type</p> <p>Tip clearance</p> <p>Side clearance</p> <p>Housing and rotor clearance</p> <p>Bypass valve setting pressure</p>	<p>Trochoid type</p> <p>0.15 mm or less</p> <p>0.10~0.15 mm</p> <p>0.03~0.09 mm</p> <p>80~120 kPa (0.8~1.2 kg/cm², 0.8~1.2 bar)</p>	<p>...</p> <p>0.15 mm</p> <p>0.35 mm</p> <p>0.14 mm</p> <p>...</p>



TIGHTENING TORQUES

ENGINE

Part to be tightened	Part name	Thread size	Q'ty	Tightening torque		Remarks
				Nm	m•kg	
Cylinder head oil check bolt	Bolt	M6	1	7	0.7	
Cylinder head and cylinder	Bolt	M8	4	22	2.2	
Cylinder head (Timing chain side)	Bolt	M8	2	20	2.0	
Cam sprocket cover	Screw	M6	2	7	0.7	with lock washer
Valve cover	Bolt	M6	5	10	1.0	
Plate	Bolt	M6	2	8	0.8	
Spark plug	—	M12	1	18	1.8	
Cylinder	Bolt	M6	2	10	1.0	
Balancer weight gear	Nut	M14	1	50	5.0	
CDI magneto	Bolt	M10	1	50	5.0	
Valve adjusting locknut	Nut	M6	2	14	1.4	
Cam sprocket	Bolt	M10	1	60	6.0	
Timing chain tensioner	Nut	M6	2	10	1.0	
Timing chain guide (intake)	Bolt	M6	2	8	0.8	with lock washer
Oil pump	Screw	M6	3	7	0.7	
Oil pump and crankcase	Screw	M6	3	7	0.7	
Drain bolt	Bolt	M35	1	43	4.3	
Oil filter cover	Screw	M6	2	7	0.7	
Drain bolt (oil filter)	Bolt	M6	1	10	1.0	
Carburetor joint and carburetor	Screw	M6	2	12	1.2	
Carburetor joint and cylinder	Screw	M5	1	2	0.2	
Carburetor joint and air filter	Screw	M5	1	2	0.2	
Air filter case	Screw	M6	1	10	1.0	
Air filter case and frame	Screw	M6	2	10	1.0	with lock washer
Muffler and frame	Bolt	M8	2	27	2.7	
Exhaust pipe and cylinder	Bolt	M6	2	10	1.0	
Exhaust pipe and muffler	Bolt	M8	1	20	2.0	
Crankcase (left and right)	Screw	M6	12	7	0.7	
Crankcase cover (left)	Screw	M6	8	7	0.7	
Crankcase cover (right)	Screw	M6	10	7	0.7	
Drive sprocket cover	Screw	M6	4	7	0.7	
Starter clutch	Bolt	M8	3	30	3.0	
Kick crank	Bolt	M8	1	20	2.0	
Primary drive gear	Nut	M14	1	50	5.0	with lock washer
Clutch spring	Screw	M5	4	6	0.6	
Clutch boss	Nut	M14	1	70	7.0	with lock washer
Push lever axle	Screw	M8	1	12	1.2	
Push lever adjuster	Nut	M6	1	8	0.8	
Drive sprocket	Bolt	M6	2	10	1.0	
Shift cam (Segment)	Screw	M6	1	12	1.2	



MAINTENANCE SPECIFICATIONS

SPEC



Part to be tightened	Part name	Thread size	Q'ty	Tightening torque		Remarks
				Nm	m•kg	
Shift pedal	Bolt	M6	1	10	1.0	
Pick up coil	Screw	M6	2	7	0.7	
Neutral switch	Screw	M10	1	20	2.0	
Stator coil	Screw	M6	3	7	0.7	
Starter motor	Screw	M6	1	7	0.7	



Item	Standard	Limit
<p>Tightening sequence Cylinder head</p>		
<p>Crankcase</p>		



MAINTENANCE SPECIFICATIONS

SPEC

CHASSIS

Item	Standard	Limit
Steering system:		
Steering bearing type	Ball bearing	...
No./size of steel balls (upper)	22 pcs. 0.1875 in	...
(lower)	19 pcs. 0.251 in	...
Front suspension:		
Front fork travel	200 mm	...
Fork spring free length	403.5 mm	399 mm
Fitting length	398.4 mm	...
Collar length	160 mm	...
Spring rate (K1)	5.0 N/mm (0.50 kg/mm)	...
(K2)	6.5 N/mm (0.65 kg/mm)	...
Stroke (K1)	0 ~ 140 mm	...
(K2)	140 ~ 200 mm	...
Oil capacity	0.294 L (294 cm ³)	...
Oil level	117 mm	...
Oil grade	Fork oil 10 WT or equivalent	...
Inner tube vend limit	...	0.2 mm
Rear suspension:		
Shock absorber stroke	82 mm	...
Spring free length	279 mm	276 mm
Fitting length	265 mm	...
Spring rate (K1)	45.2 N/mm (4.52 kg/mm)	...
(K2)	72.2N/mm (7.22 kg/mm)	...
Stroke (K1)	0 ~ 42 mm	...
(K2)	42 ~ 62 mm	...
Front wheel:		
Type	Spoke wheel	...
Rim size	21 × 1.60	...
Rim material	Steel	...
Rim runout limit radial	...	2 mm
lateral	...	2 mm
Rear wheel:		
Type	Spoke wheel	...
Rim size	18 × 1.85	...
Rim material	Steel	...
Rim runout limit radial	...	2 mm
lateral	...	2 mm
Drive chain:		
Type/manufacturer	DID428HDS/DAIDO	...
No. of links	122	...
Chain free play	30~45 mm	...

MAINTENANCE SPECIFICATIONS

SPEC



Item	Standard	Limit
Front brake: Type Drum diameter Shoe thickness Shoe spring free length	Leading, trailing 130 mm 4.0 mm 50.5 mm	... 131 mm 2.0 mm ...
Rear brake: Type Drum inside diameter Shoe thickness Shoe spring free length	Leading, trailing 130 mm 4.0 mm 50.5 mm	... 131 mm 2.0 mm ...
Brake lever: Brake lever free play (at lever end)	10~20 mm	...
Brake pedal: Brake pedal free play Brake pedal position	20~30 mm 10 mm
Clutch lever: Clutch lever free play (at lever end)	10~15 mm	...
Throttle cable free play	2~3 mm	...



TIGHTENING TORQUES

CHASSIS

Part to be tightened	Thread size	Tightening torque		Remarks
		Nm	m•kg	
Handle crown and front fork	M10	34	3.4	Refer to NOTE
Handle crown and steering shaft	M14	55	5.5	
Handlebar holder (handle crown and upper)	M 8	20	2.0	
Steering ring nut	M25	38	3.8	
Handlebar under holder and nut	M14	55	5.5	
Steering shaft and front fork	M 8	23	2.3	
Engine and front engine stay	M 8	37	3.7	
Front engine stay and frame	M 8	37	3.7	
Engine and top engine stay	M 8	33	3.3	
Top engine stay and frame	M 8	33	3.3	
Engine and engine bracket (frame)	M 8	33	3.3	
Swingarm pivot shaft	M12	80	8.0	
Rear shock absorber and frame	M10	25	2.5	
Swingarm and tension bar	M 8	20	2.0	
Tension bar and rear brake shoe plate	M 8	20	2.0	
Fuel tank and fuel cock	M 6	7	0.7	
Footrest (left) and frame	M12	80	8.0	
Footrest (right) and frame	M10	45	4.5	
Sidestand (left)	M10	30	3.0	
(right)	M10	30	3.0	
Front wheel axle and nut	M10	39	3.9	
Rear wheel axle and nut	M14	80	8.0	
Driven sprocket and clutch hub	M 8	30	3.0	
Driven sprocket and axle	M20	80	8.0	
Meter gear and meter cable	M12	3	0.3	
Brake cam lever	M 6	9	0.9	
Rear carrier and frame	M10	30	3.0	
Chain case protector and swingarm	M 8	15	1.5	

NOTE:

1. When tighten the ring nut, should be steady the ball bearings and the steering shaft moving smoothly.
2. First, tighten the ring nut approximately 38 Nm (3.8 m•kg) by using the torque wrench, then loosen the ring nut until the steering shaft moving smoothly.



ELECTRICAL

Item	Standard	limit
Ignition timing: Ignition timing (B.T.D.C.) Advanced timing Advanced type	9° at 1,300 r/min 29° at 6,000 r/min Electrical type
CDI: CDI magneto model/manufacturere Pickup coil resistance/color Source coil 1 resistance/color Source coil 2 resistance/color CDI unit model/manufacturere	F3GX/YAMAHA 656~984 Ω at 20°C/ Red — White 700~900 Ω at 20°C/ Brown — Green 472~708 Ω at 20°C/ Yellow — Green 3GX/YAMAHA
Ignition coil: Model/manufacturere Minimum spark gap Primary winding resistance Secondary winding resistance	2JN/YAMAHA 6 mm 0.27~0.33 Ω at 20°C 5.76~8.52 kΩ at 20°C
Spark plug cap: Type Resistance	Resin type 10 kΩ
Charging system: Type Model/manufacturere Standard output Stator coil resistance/color	CDI magneto F3GX/YAMAHA 14 V 12 A/5,000 r/min 0.48~0.72 Ω at 20°C/ White — White
Rectifier/regulator: Model/manufacturere Type (regulator) No load regulated voltage Capacity (rectifier) Withstand voltage	SH569A-12/SHINDENGEN Semi conductor - short circuit type 14.1~14.9 V 25 A 240 V
Battery: Specific gravity	1.320	...
Electric starter system: Type Starter motor: Model/manufacturere Output Armature coil resistance Brush overall length Brush spring pressure	Constant mesh type 3GX/YAMAHA 0.4 kW 0.0171~0.0207 Ω at 20°C 10 mm 5.49~6.24 N (560~840g) 3.5 mm ...

MAINTENANCE SPECIFICATIONS

SPEC




Item	Standard	limit
Commutator diameter Mica undercut (depth)	22 mm 1.5 mm	21 mm ...
Starter relay: Model/manufacturer Amperage rating Coil winding resistance	4FU/JIDECO 100 A 3.9~4.7 Ω at 20°C
Horn: Model/manufacturer Maximum amperage	GF-12/NIKKO 1.5 A
Flasher relay: Type Model/manufacturer Flasher frequency	Full transistor type FE218BH/DENSO 85 cycle/min
Starting circuit cut-off relay: Model/manufacturer Coil winding resistance	ACA12115-3/MATSUSHITA 72~88 Ω at 20°C
Circuit breaker: Type Main Reserve Auxiliary DC terminal Reserve	Fuse 20 A × 1 pcs. 20 A × 1 pcs. 10 A × 1 pcs. 10 A × 1 pcs.

GENERAL TORQUE SPECIFICATIONS

This chart specifies torque for standard fasteners with standard I.S.O. pitch threads. Torque specifications for special components or assemblies are included in the applicable sections of this book. To avoid warpage, tighten multi-fastener assemblies in a crisscross fashion, in progressive stages, until full torque is reached. Unless otherwise specified, torque specifications call for clean, dry threads. Components should be at room temperature.

A (Nut)	B (Bolt)	General torque specifications	
		Nm	m•kg
10 mm	6 mm	6	0.6
12 mm	8 mm	15	1.5
14 mm	10 mm	30	3.0
17 mm	12 mm	55	5.5
19 mm	14 mm	85	8.5
22 mm	16 mm	130	13.0



A: Distance across flats
B: Outside thread diameter


**LUBRICATION POINT AND GRADE OF LUBRICANT
ENGINE**

Lubrication Point	Symbol
Oil seal lips (all)	
Bearing retainer (all)	
Bolt (cylinder head)	
Crank pin	
Connecting rod (big end)	
Piston pin	
Piston/piston ring	
Buffer boss	
Valve stem/valve guide (IN, EX)	
Valve stem end (IN, EX)	
Rocker arm shaft	
Cam and bearing (camshaft)	
Rocker arm inner surface	
Crankcase mating surfaces	Yamaha bond No. 1215
O-rings (all)	
Kick gear inside	
Kick idle gear inside	
Kick crank boss	
Starter idle gear thrust surfaces	
Starter clutch (outer/roller)	
Starter wheel gear inner surface	
Push rod	
Primary driven gear inner surface	
Push lever axle	
Transmission gear inner surface	
Shift fork/guide bar/shift shaft/shift cam	

LUBRICATION POINT AND GRADE OF LUBRICANT

SPEC




CHASSIS

Lubrication Point	Symbol
Steering head pipe bearing (upper/lower)	
Front wheel oil seal lips (left/right)	
Rear wheel oil seal lips (left/right)	
Rear wheel hub	
Front/rear brake, camshaft and pivoting pin	
Sidestand sliding surface/mounting bolt	
Tube guide (throttle grip) inner surface	
Clutch lever bolt/collar/cable sliding surface	
Gear unit (speedometer)	
Swingarm pivot shaft and bush	
Rear shock absorber bush (swing arm side)	
Swingarm grease nipple	


**LUBRICATION DIAGRAM**

- ① Rocker arm (IN)
- ② Rocker shaft
- ③ Rocker arm (EX)
- ④ Camshaft
- ⑤ Oil pump
- ⑥ Push lever








- ① Oil pump
- ② Oil filter
- ③ Crankshaft
- ④ Main axle
- ⑤ Drive axle
- ⑥ Oil strainer




**CABLE ROUTING**

- | | | |
|---------------------------------|---------------------------------|---------------------------------|
| ① Auxiliary DC terminal | ⑬ Rear carrier | ⑳ Front flasher lead |
| ② Throttle cable | ⑭ Clamp | ㉑ Clutch switch coupler |
| ③ Front brake switch lead | ⑮ Rear flasher lead (right) | ㉒ Front fork breather hose |
| ④ Brake cable | ⑯ Clamp | ㉓ Handlebar switch lead (right) |
| ⑤ Handlebar switch lead (right) | ⑰ Rear flasher lead (left) | ㉔ Wireharness |
| ⑥ Handlebar switch lead (left) | ⑱ Wireharness | ㉕ Flasher relay |
| ⑦ Clutch switch lead | ㉑ Rectifier/Regulator | |
| ⑧ Clutch cable | ㉒ Front brake switch coupler | |
| ⑨ Cable guide | ㉓ Main switch coupler | |
| ⑩ Speedometer | ㉔ Auxiliary DC terminal coupler | |
| ⑪ Main switch | ㉕ Meter lead | |
| ⑫ Battery positive lead | ㉖ Front flasher lead (left) | |






- A Clamp the handlebar switch lead (right) and front brake switch lead to the handlebar.
- B Clamp the handlebar switch lead (left) and clutch switch lead to the handlebar.
- C From the left side:
Front flasher lead (right), handlebar switch lead (right), main switch lead, terminal lead, meter lead and front flasher lead (left).




- ① Clamp
- ② Speedometer cable
- ③ Front brake cable
- ④ Cable guide
- ⑤ Front flasher lead
- ⑥ Band
- ⑦ Clutch cable
- ⑧ Starter cable
- ⑨ Handlebar switch lead
- ⑩ Throttle cable
- ⑪ Clamp
- ⑫ Neutral relay
- ⑬ CDI unit
- ⑭ CDI unit lead
- ⑮ Band
- ⑯ Rear shock absorber
- ⑰ Pulsar coil lead
- ⑱ Wireharness
- ⑲ Charge coil lead
- ⑳ Fuel hose
- ㉑ Starter motor lead
- ㉒ Band
- ㉓ Rectifier/Regulator lead
- ㉔ Rear brake switch lead
- ㉕ Clamp
- ㉖ Starter relay lead
- ㉗ Horn





- A** Pass the front flasher lead behind the front carrier and in front of the starter cable.
- B** Pass the clutch cable outside of the wireharness.
- C** Clamp the clutch cable, starter cable, handlebar switch lead and throttle cable.
- D** Bind the wireharness, CDI unit lead, throttle cable, pulsar coil lead, neutral lead and charge coil lead together front and rear, before insert the cover.
- E** Band the wireharness, CDI unit lead, and starting motor lead.
- F** Mating with the top on the wireharness to the seat pillar tube.
- G** Band pulsar coil lead, charge coil lead, neutral lead, and starting motor lead.
- H** Pass the CDI unit lead, throttle cable and starter cable into the center of the engine stay, with the wireharness positioned leftest, then band them together.
- I** Pass the starter cable in front of the throttle cable and clutch cable.
- J** Clamp the handlebar switch lead and the clutch cable.
- K** Pass the throttle cable and clutch cable in to the cable guide.
- L** Pass the starter cable and handlebar switch lead out side of the cable guide.






- ① Fuse holder (auxiliary DC terminal)
- ② Wireharness
- ③ Battery positive lead
- ④ Clamp
- ⑤ Battery
- ⑥ Battery negative lead
- ⑦ High tension cord
- ⑧ Ignition coil
- ⑨ Ground lead
- ⑩ Ignition coil primary lead
- ⑪ Horn
- ⑫ Air vent pipe

- ⑬ Starter motor lead
- ⑭ Breather hose
- ⑮ Magneto lead
- ⑯ Over flow hose
- ⑰ Rear brake switch
- ⑱ Rear brake switch lead
- A Insert the fuse holder into the mud guard projection.
- B Tighten the ground lead together with the front bolt.
- C Adjust the cable position, do not allow the starter cable to contact the cylinder.

- D Pass the air vent pipe into the clamp.



EB300000

PERIODIC INSPECTIONS AND ADJUSTMENTS

INTRODUCTION

This chapter includes all information necessary to perform recommended inspections and adjustments. These preventive maintenance procedures, if followed, will ensure more reliable vehicle operation and a longer service life. The need for costly overhaul work will be greatly reduced. This information applies to vehicles already in service as well as to new vehicles that are being prepared for sale. All service technicians should be familiar with this entire chapter.

YP301000

PERIODIC MAINTENANCE/LUBRICATION INTERVALS

NO.	ITEM	ROUTINE	BRAKE-IN 1,000 KM	EVERY	
				6,000 km or 6 months	12,000 km or 12 months
1 *	Valve(s)	Check valve clearance. Adjust if necessary.	○	○	○
2 *	Spark plug	Check condition. Clean or replace if necessary.	○	○	○
3	Air filter	Clean. Replace if necessary.		○	○
4	Carburetor	Check idle speed/starter operation. Adjust if necessary.	○	○	○
5 *	Fuel line	Check fuel hose for cracks or damage. Replace if necessary.		○	○
6 *	Engine oil	Replace (Warm engine before draining.)	○	○	○
7 *	Engine oil strainer	Clean.	○		○
8 *	Engine oil filter	Clean.	○		○
9 *	Brake	Check operation. Adjust if necessary.		○	○
10 *	Clutch	Check operation. Adjust if necessary.		○	○
11 *	Rear arm pivot	Check rear arm assembly for looseness. Moderately repack.**	CHECK	○	○
12	Wheels	Check balance/damage/runout/spoke tightness. Replace if necessary.	○	○	○
13	Wheel bearings	Check bearing assembly for looseness/damage. Replace if damaged.		○	○
14 *	Steering bearing	Check bearing assembly for looseness. Correct if necessary. Moderately repack every 24,000 km or 24 months. **	CHECK		CHECK
15 *	Front forks	Check operation/oil leakage. Repair if necessary.		○	○
16 *	Rear shock absorber	Check operation/oil leakage. Repair if necessary.		○	○

*: It is recommended that these items be serviced by a Yamaha dealer.

** : Light weight lithium-soap base grease

2

PERIODIC MAINTENANCE/LUBRICATION INTERVALS

INSP	
ADJ	

NO.	ITEM	ROUTINE	BRAKE-IN 1,000 KM	EVERY	
				6,000 km or 6 months	12,000 km or 12 months
17	Drive chain	Check chain slack/alignment. Adjust if necessary. Clean and lube.	EVERY 500 km		
18*	Chassis fasteners	Check all chassis fittings and fasteners. Correct if necessary.	○	○	○
19*	Sidestand	Check operation. Repair if necessary.	○	○	○

*: It is recommended that these items be serviced by a Yamaha dealer.


** : Light weight lithium-soap base grease.

NOTE: _____

The air filter needs more frequent service if you are riding in unusually wet or dusty areas.

3

SIDE COVER, SEAT AND FUEL TANK







Order	Job name/Part name	Q'ty	Remarks
	Side cover, seat and fuel tank removal		Remove the parts in order.
1	Side cover (left)	1	NOTE: Before disconnect the fuel hose, turn the fuel cock lever "OFF" position.
2	Side cover (right)	1	
3	Seat	1	
4	Fuel hose	1	
5	Fuel tank	1	
			Reverse the removal procedure for installation.

SR03004

**ENGINE
VALVE CLEARANCE ADJUSTMENT**


NOTE: _____

Valve clearance adjustment should be made with the engine cool, at room temperature. When the valve clearance is to be measured or adjusted, the piston must be at Top Dead Center (T.D.C.) on the compression stroke.



1. Remove:
 - Seat
 - Side cover (left and right)
 - Fuel tank
Refer to "SIDE COVER, SEAT AND FUEL TANK" section .
2. Remove:
 - Spark plug cap ①
 - Spark plug
 - Valve cover (intake side) ②
 - Valve cover (exhaust side) ③
3. Remove:
 - Timing check plug (with O-ring) ①
 - Center plug (with O-ring) ②


4. Measure:
 - Valve clearance
Out of specification → Adjust.

	Valve clearance (cold):
	Intake valve 0.10 ~ 0.14 mm
	Exhaust valve 0.16 ~ 0.20 mm

Measurement steps:

- Rotate the crankshaft counterclockwise to align the slit (a) on the rotor with the stationary pointer (b) on the crankcase cover (left) when the piston is Top Dead Center (T.D.C.).
- Measure the valve clearance by using a feeler gauge.
Out of specification → Adjust clearance.

VALVE CLEARANCE ADJUSTMENT/ IDLING SPEED ADJUSTMENT





5. Adjust:
- Valve clearance



Adjustment steps:

- Loosen the locknut ①.
- Turn the adjuster ③ in or out with the valve adjusting tool ② until specified clearance is obtained.



Turning in → Valve clearance is decreased.
Turning out → Valve clearance is increased.


 **Valve adjusting tool:
90890-01311**

- Hold the adjuster to prevent it from moving and tighten the locknut.
-  **14 Nm (1.4 m•kg)**
- Measure the valve clearance.
 - If the clearance is incorrect, repeat above steps until specified clearance is obtained.

6. Install:
- Valve cover (intake side) ①
-  **10 Nm (1.0 m•kg)**
- O-ring ②
 - Valve cover (exhaust side) ③
-  **10 Nm (1.0 m•kg)**
- O-ring ④

A Intake side
B Exhaust side





7. Install:
- Spark plug
-  **18 Nm (1.8 m•kg)**
- Timing check window screw ① (with O-ring)
 - Center plug ② (with O-ring)

YP303022

IDLING SPEED ADJUSTMENT

1. Start the engine and let it warm up for several minutes.
2. Attach:
 - Engine tachometer to the spark plug lead.



 **Engine tachometer:
90890-03113**



3. Check:
- Engine idling speed
Out of specification → Adjust.



Engine idling speed:
1,300 ~ 1,400 r/min

4. Adjust:
- Engine idle speed

Adjustment steps:

- Turn the pilot screw ① until it is lightly seated.
- Turn the pilot screw out by the specified number of turns.





Pilot screw:
2 turns out

- Turn the throttle stop screw ② in or out until the specified idling speed is obtained.

Turning in → Idling speed is increased.

Turning out → Idling speed is decreased.

5. Adjust:
- Throttle cable free play
Refer to "THROTTLE CABLE ADJUSTMENT" section.



YP303032

THROTTLE CABLE ADJUSTMENT

NOTE: _____

Prior to adjusting the throttle cable free play, the engine idling speed should be adjusted.

1. Check:
- Throttle cable free play ①
Out of specification → Adjust.



Free play (throttle cable):
3~5 mm at throttle grip flange

2. Adjust:
- Throttle cable free play

Adjustment steps:

NOTE: _____


Never accelerate the throttle when stopping the engine.

THROTTLE CABLE ADJUSTMENT/ SPARK PLUG INSPECTION

**INSP
ADJ**



D



- Loosen the locknut ① on the throttle cable.
- Turn the adjuster ② in or out until specified free play is obtained.

Turning in → Free play is increased.

Turning out → Free play is decreased.

- Tighten the locknut.

⚠ WARNING

After adjusting, turn the handlebar to the right and to the left to ensure that this does not cause the engine idling speed to change.

EB303040

SPARK PLUG INSPECTION

1. Remove:
 - Spark plug cap
 - Spark plug

⚠ CAUTION:

Before removing the spark plug, use compressed air to blow away any dirt accumulated in the spark plug wells to prevent it from falling into the cylinder.

2. Check:
 - Spark plug type
Incorrect → Replace.




**Standard spark plug:
D8EA/X24ES-U (NGK/DENSO)**

3. Inspect:
 - Electrode ①
Wear/damage → Replace.
 - Insulator ②
Abnormal color → Replace.
Normal color is a medium-to-light tan color.
4. Clean:
 - Spark plug
(with spark plug cleaner or wire brush)
5. Measure:
 - Spark plug gap ③
(with a wire gauge)
Out of specification → Adjust gap.



**Spark plug gap:
0.6 ~ 0.7 mm**





SPARK PLUG INSPECTION/ IGNITION TIMING CHECK

INSP ADJ	

6. Install:

- Spark plug

	18 Nm (1.8 m•kg)
--	-------------------------

NOTE: _____

Before installing a spark plug, clean the gas-ket surface and plug surface.

YP303052

IGNITION TIMING CHECK

NOTE: _____



Prior to checking the ignition timing, check all electrical connections related to the ignition system. Make sure all connections are tight and free of corrosion and that all ground connections are tight.

1. Remove:

- Timing check plug

2. Attach:

- Timing light ①
- Engine tachometer ② (to the spark plug lead)



	Timing light:
	90890-03141
	Engine tachometer:
	90890-03113

3. Check:

- Ignition timing

Checking steps:

- Start the engine and let it warm up for several minutes. Let the engine run at the specified speed.

	Engine idling speed:
	1,300 ~ 1,400 r/min


- Visually check the stationary pointer (a) to verify it is within the required firing range (b) indicated on the flywheel. Incorrect firing range → Check the ignition system.

NOTE: _____

Ignition timing is not adjustable.

3. Install:

- Timing check plug



SR303060

COMPRESSION PRESSURE MEASUREMENT


NOTE: _____

Insufficient compression pressure will result in performance loss.


1. Check:
 - Valve clearance
Out of specification → Adjust.
Refer to "VALVE CLEARANCE ADJUSTMENT" section.
2. Start the engine and let it warm up for several minutes.
3. Turn off the engine.
4. Remove:
 - Spark plug

CAUTION: _____

Before removing the spark plug, use compressed air to blow away any dirt accumulated in the spark plug well to prevent it from falling into the cylinder.



5. Attach:
 - Compression gauge ①

	<p>Compression gauge: ① 90890-03081</p> <p>Adaptor: ② 90890-04082</p>
---	---

6. Measure:
 - Compression pressure
If it exceeds the maximum pressure allowed → Inspect the cylinder head, valve surfaces and piston crown for carbon deposits.
If it is below the minimum pressure → Squirt a few drops of oil into the affected cylinder and measure again.
Follow the table below.

Compression pressure (With oil applied into cylinder)	
Reading	Diagnosis
Higher than without oil	Worn or damaged pistons
Same as without oil	Possible defective ring(s), valves, cylinder head gasket or piston → Repair.



Compression pressure (at sea level):
Standard:
 900 kPa (9.0 kg/cm² , 9.0 bar)
Minimum:
 800 kPa (8.0 kg/cm² , 8.0 bar)
Maximum:
 1,000 kPa (10.0 kg/cm² , 10.0 bar)

Measurement steps:

- Crank the engine with the throttle wide-open until the reading on the compression gauge stabilizes.

WARNING

Before cranking the engine, ground all spark plug leads to prevent sparking.

7. Install:

- Spark plug  **18 Nm (1.8 m•kg)**

YP303070

ENGINE OIL LEVEL INSPECTION

- Stand the motorcycle on a level surface.

NOTE:

Make sure the motorcycle is upright when inspecting the oil level.



- Start the engine and let it warm up for a few minutes.
- Turn off the engine.
- Inspect:
 - Engine oil level
 Oil level should be between maximum ① and minimum ② marks.
 Oil level is below the minimum mark
 →Add oil up to the proper level.


RECOMMENDED ENGINE OIL

Refer to the chart for selection of the oils suited to the atmospheric temperature.



Recommended oil:
 Refer to the following chart for selection of oils which are suited to the atmospheric temperatures.
Recommended engine oil classification:
API STANDARD:
 API "SE" or higher grade








CAUTION:

- Do not put in any chemicals additives or use oils with a grade of CD **a** or higher.
- Be sure not to use oils labeled "ENERGY CONSERVING II" **b** or higher. Engine oil also lubricates the clutch and additives could cause clutch slippage.
- Be sure no foreign material enters the crankcase.

5. Start the engine and let it warm up for a few minutes.
6. Turn off the engine and inspect the oil level once again.

NOTE:

Wait a few minutes until the oil settles before inspecting the oil level.




SR303082

ENGINE OIL REPLACEMENT

1. Start the engine and let it warm up for several minutes.
2. Turn off the engine and place a container under the engine.
3. Remove:
 - Oil filler plug **1**
 - Drain plug **2**
 Drain the crankcase of its oil.
4. Loosen:
 - Bolt **1** (oil filter cover-lower)
5. Drain the crankcase of its oil.
If the oil filter is to be replaced during this procedure, remove the following parts and reinstall them afterwards.


Replacement steps:

- Remove the oil filter cover **1** and oil filter element **2**.
- Check the O-ring **3**. If it is cracked or damaged, replace it.
- Install the oil filter element and oil filter cover.

	Screw:
	7 Nm (0.7 m•kg)
	Bolt:
	10 Nm (1.0 m•kg)

6. Install:

- Drain plug

 **43 Nm (4.3 m·kg)**

NOTE: _____


Inspect the O-ring. If it is damaged, replace it with a new one.

CAUTION: _____

Before reinstalling the drain plug, do not forget to fit the O-ring, compression spring and oil strainer. Be sure you fit each item in the correct position and order.

7. Fill:

- Crankcase

	Oil quantity:
	With oil filter change
	1.1 L
	Without oil filter change
	1.0 L


Refer to "ENGINE OIL LEVEL INSPECTION" section.


8. Inspect:

- Oil flow

Inspection steps:

- Slightly loosen the oil check bolt ①.
- Start the engine and keep it idling until the oil begins to seep from the oil check bolt. If no oil comes out after one minute, turn the engine off so it will not seize.
- Check oil passages and oil pump for damage or leakage.
- Start the engine after solving the problem(s), and recheck the oil pressure.
- Tighten the oil check bolt to specification.





	Oil check bolt: 7 Nm (0.7 m·kg)
---	--

EB303093

CLUTCH ADJUSTMENT

1. Check:
 - Clutch cable free play ①
 Out of specification → Adjust.



	Free play (clutch lever):
	10 ~ 15 mm
	at clutch lever end

2. Adjust:
 - Clutch cable free play

Adjustment steps:

Crankcase side

- Make sure that the adjuster ① and locknut ② are fully tightened.
- Loosen the locknut ②.
- Turn the adjuster ① in or out until the specified free play is obtained.


Turning in → Free play is decreased.

Turning out → Free play is increased.
--

- Tighten the locknut ②.

NOTE:

If the amount of free play is still incorrect, adjust the clutch cable free play with the other adjuster (on the clutch lever holder).




Lever side





- Loosen the locknut ③.
- Turn the adjuster ④ in or out until the specified free play is obtained.

Turning in → Free play is increased.

Turning out → Free play is decreased.
--

- Tighten the locknut ③.





AG303123

AIR FILTER CLEANING

1. Remove:

- Side cover (left)
- Air filter case cover ①
- Air filter element holder ②
- Air filter element ③

CAUTION:

Never operate the engine without the air filter element installed. Unfiltered air will cause rapid wear of engine parts and may damage the engine. Operating the engine without the filter element will also affect the carburetor tuning, leading to poor engine performance and possible overheating.

2. Inspect:

- Air filter element ①
- Damage → Replace.

3. Clean:

- Air filter element
- Use solvent to clean the element.

NOTE:

After cleaning, remove the remaining solvent by squeezing the element.

CAUTION:

Do not twist the filter element when squeezing it.


WARNING

Never use low flash point solvents such as gasoline to clean the air filter element. Such solvents may cause a fire or an explosion.


4. Apply the recommended oil to the entire surface of the filter and squeeze out the excess oil. The element should be wet but not dripping.



Recommended oil:
Engine oil




5. Install:
- Air filter element ①
 - Air filter element holder ②
 - Air filter case cover ③
 - Side cover (left)



EXHAUST SYSTEM INSPECTION

1. Inspect:
- Exhaust pipe ①
 - Muffer ②
 - Crack/Damage → Replace.
 - Gasket ③
 - Exhaust gas leaks → Replace.
2. Check:
- Tightening torque

	Bolt ④: 10 Nm (1.0 m·kg)
	Bolt ⑤: 20 Nm (2.0 m·kg)
	Bolt ⑥: 27 Nm (2.7 m·kg)



EB304002

CHASSIS**FRONT BRAKE ADJUSTMENT**

1. Check:

- Brake lever free play (a)

Out of specification → Adjust.



Free play (Brake lever):
10 ~ 20 mm
at brake lever end

2. Adjust:

- Brake lever free play

Adjustment steps:**Lever side**

- Loosen the locknut (1).
- Turn the adjuster (2) in or out until the specified free play is obtained.

Turning in → Free play is decreased.

Turning out → Free play is increased.

- Tighten the locknut.

CAUTION

Make sure that there is no brake drag after adjusting the front brake lever free play.




Wheel side

- Loosen the locknut (3).
- Turn the adjuster (4) in or out until the specified free play is obtained.

Turning in → Free play is decreased.

Turning out → Free play is increased.

- Tighten the locknut.



EB304012

REAR BRAKE ADJUSTMENT

1. Check:


- Brake pedal height (a)

Out of specification → Adjust.



Brake pedal height:
10 mm
below the top of the footrest

REAR BRAKE ADJUSTMENT



2. Adjust:
- Brake pedal height

Adjustment steps:


- Loosen the locknut ①.
- Turn the adjuster ② in or out until the specified pedal height is obtained.


Turning in → Pedal height is decreased.
Turning out → Pedal height is increased.

- Tighten the locknut.

3. Check:

- Brake pedal free play ③
- Out of specification → Adjust.

 Free play (Brake pedal): 20 ~ 30 mm at brake lever end




4. Adjust:

- Brake pedal free play

Adjustment steps:

- Turn the adjuster ① in or out until the specified free play is obtained.

Turning in → Free play is decreased.
Turning out → Free play is increased.




CAUTION:

Make sure that there is no brake drag after adjusting the brake pedal height and the free play.

5. Adjust:

- Brake light switch
- Refer to "BRAKE LIGHT SWITCH ADJUSTMENT".

BRAKE SHOE INSPECTION/ BRAKE LIGHT SWITCH ADJUSTMENT/ DRIVE CHAIN SLACK ADJUSTMENT



EB304040

BRAKE SHOE INSPECTION


1. Operate the brake lever or brake pedal.
2. Inspect:
 - Brake shoes
 Wear indicator ① reaches the wear limit line ② → Replace the brake shoes as a set.
 Refer to "REAR WHEEL" in CHAPTER 6.

EB304050

BRAKE LIGHT SWITCH ADJUSTMENT

NOTE: _____

- The brake light switch is operated by movement of the brake pedal.
- Adjustment is correct when the brake light comes on just before the braking effect actually starts.



1. Check:
 - Brake light operation timing
 - Incorrect → Adjust.
2. Adjust:
 - Brake light operating timing

Adjustment steps:

- Hold the main body ① of the switch with your hand so that it does not rotate, and turn the adjuster ② in or out until the proper operation timing is obtained.

Turning in → Brake light comes on fast.

Turning out → Brake light comes on slow.

AG304091

DRIVE CHAIN SLACK ADJUSTMENT

NOTE: _____

Before checking and adjusting, rotate the rear wheel several revolutions and check the slack at several points to find the tightest point. Check and if necessary adjust the drive chain slack with the rear wheel in this "tightest" position.

CAUTION


Too little chain slack will overload the engine and other vital parts; keep the slack within the specified limits.

WARNING


- Securely support the motorcycle so that there is no danger of it falling over.
- Hold the motorcycle upright on a level surface.

NOTE:


Both wheels should be on the ground and nobody should sit on the motorcycle while this adjustment is being performed.



1. Remove:
 - Cap
2. Check:
 - Drive chain slack (a)
 Out of specification → Adjust.

	Drive chain slack: 30 ~ 45 mm
---	---

① Check window





3. Remove:
 - Cotter pin ①
4. Adjust:
 - Drive chain slack

Adjustment steps:

- Loosen the rear brake adjuster.
- Loosen the axle nut ② and the sprocket shaft nut ③.
- Turn the chain adjusters ④ clockwise or counterclockwise until the specified drive chain slack is obtained.


Clockwise → Chain slack is decreased.
Counter-clockwise → Chain slack is increased.



NOTE:

Turn each chain adjuster exactly the same amount to maintain correct axle alignment. (There are marks ⑤ on each chain adjuster. Use them when adjusting the slack for proper alignment.)

- Before tightening the axle nut to specification, make sure that there is no clearance at the adjuster (or the swingarm end) on both sides by pushing the wheel forward.

	Driven sprocket shaft: 80 Nm (8.0 m•kg)
	Rear wheel axle: 80 Nm (8.0 m•kg)

5. Install:

- Cotter pin ⑥ **New**
Into the axle nut and bend the end of the cotter pin.

CAUTION:

Do not loosen the axle nut after tightening the torque. If the axle nut groove is not aligned with the cotter pin hole, align the groove with the hole by tightening up the axle nut.

WARNING

Always use a new cotter pin

6. Adjust:

- Brake pedal free play
Refer to "BRAKE PEDAL FREE PLAY" section.

EB304130

STEERING HEAD INSPECTION



⚠WARNING

Securely support the motorcycle so that there is no danger of it falling over.

1. Stand the motorcycle on a level surface.


NOTE:

Stand the motorcycle on its centerstand if it has one. If not, place a suitable stand under the engine.




2. Elevate the front wheel by placing a suitable stand under the engine.
3. Check:
 - Steering assembly bearings
Grasp the bottom of the lower front fork tubes and gently rock the fork assembly.
Looseness → Adjust the steering head.
4. Adjust:
 - Steering head


Adjustment steps:

- Loosen the handle crown bolt ① .
- Tighten the ring nut ② using the ring nut wrench ③.  38 Nm (3.8 m·kg)
- Loosen the ring nut.

NOTE:

When loosen the ring nut, should be steady the ball bearings and steering shaft moving smoothly.




- Tighten the handle crown bolt ①.  55 Nm (5.5 m·kg)
- Check the steering head for looseness or binding by turning it all the way in both directions.

EB304140

FRONT FORK INSPECTION

▲WARNING

Securely support the motorcycle so that there is no danger of it falling over.



1. Stand the motorcycle on a level surface.
2. Check:
 - Inner tube
Scratches/damage → Replace.
 - Oil seal
Excessive oil leakage → Replace.
Hold the motorcycle upright and apply the front brake.
3. Check:
 - Operation
Push down hard on the handlebars several times.
Unsmooth operation → Repair.
Refer to "FRONT FORK" in CHAPTER 6.

EB304160

REAR SHOCK ABSORBER ADJUSTMENT

▲WARNING

Securely support the motorcycle so that there is no danger of it falling over.

Spring preload:

1. Remove:
 - Seat
2. Adjust:
 - Spring preload

NOTE:

Use the special wrench and extension bar included in the owner's tool kit to adjust the spring preload.

Adjustment steps:


- Turn the adjuster ① to direction ② or ③.

Turning toward ②

→Spring preload is increased.


Turning toward ③

→Spring preload is decreased.



REAR SHOCK ABSORBER ADJUSTMENT/ TIRE INSPECTION

INSP	
ADJ	



Adjustment numbers:	
Standard number:	5
Minimum number:	5
Maximum number:	1

CAUTION:


Never turn the adjuster beyond the maximum or minimum adjustment number.

3. Install:
 - Seat

EB304171

TIRE INSPECTION

1. Measure:
 - Tire inflation pressure
 - Out of specification → Adjust.



WARNING


- Tire inflation pressure should only be checked and adjusted when the tire temperature equals the ambient air temperature. Tire inflation pressure and suspension must be adjusted according to the total weight of the cargo, rider and accessories (fairing, saddlebags, etc.if approved for this model), and according to whether the motorcycle will be operated at high speed or not.

NEVER OVERLOAD THE MOTORCYCLE.


- Operation of an overloaded motorcycle could cause tire damage, accident or injury.

Basic weight:	127 kg	
With oil and full fuel tank		
Maximum load*	112 kg	
	Front	Rear
Cold tire pressure	120 kPa (1.2 kg/cm ² , 1.2 bar)	150 kPa (1.5 kg/cm ² , 1.5 bar)

* Load is the total weight of the cargo, rider, and accessories.



2. Inspect:
 - Tire surfaces
 Wear/damage → Replace.

	Minimum tire tread depth (front and rear): 1.6 mm
---	--

- ① Tread depth
- ② Side wall
- ③ Wear indicator

⚠ WARNING

- It is dangerous to ride with a worn-out tire. When the tire tread begins to show signs of wear, replace the tire immediately.
- Patching a punctured tube is not recommended. If it is absolutely necessary to do so, use great care and replace the tube as soon as possible with a good quality replacement tube.
- Do not use tubeless tires on a wheel designed for tube type tires only. Tire failure and personal injury may result from sudden deflation.


Tube type wheel → Tube type tire only
Tubeless type wheel → Tube type or tubeless tire.


- Be sure to install the correct tube when using tube type tires.
- After extensive tests, the tires listed below have been approved by Yamaha Motor Co., Ltd. for this model. No guarantee concerning handling characteristics can be given if a tire combination other than one approved by Yamaha is used on this motorcycle. The front and rear tires should always be by the same manufacturer and of the same design.

⚠ WARNING

After mounting a tire, ride conservatively for a while to give the tire time to seat itself properly in the rim. Failure to do so could lead to an accident with possible injury to the rider or damage to the motorcycle.


2. After a tire repair or replacement, be sure to tighten the valve stem locknut ① to specification.

	Locknut: 1.5 Nm (0.15 m·kg)
---	--



341 009

SPOKE INSPECTION AND TIGHTENING/ WHEEL INSPECTION




EB304190


SPOKE INSPECTION AND TIGHTENING

1. Inspect:
 - Spokes ①
 - Bending/damage → Replace.
 - Loose spoke → Retighten.
2. Tighten:
 - Spokes

NOTE: _____

Be sure to tighten the spokes before and after break-in.



	Nipple: 2 Nm (0.2 m•kg)
---	-----------------------------------


EB304180

WHEEL INSPECTION

1. Inspect:
 - Wheels
 - Damage/Bends → Replace.

NOTE: _____

Always balance the wheel when a tire or wheel has been changed or replaced.



▲WARNING _____

Never attempt to make any repairs to the wheel.



AG305000

ELECTRICAL BATTERY INSPECTION

NOTE: _____

Since the MF battery is a sealed type battery, it is not possible to measure the specific gravity of the electrolyte in order to check the charge state of the battery. Therefore the charge of the battery has to be checked by measuring the voltage at the battery terminals.

CAUTION: _____

CHARGING METHOD

- This is a sealed type battery. Never remove the sealing caps. If the sealing caps have been removed, the balance will not be maintained and battery performance will deteriorate.
- Charging time, charging current and charging voltage for the MF battery are different from those of batteries of general type.
- The MF battery should be charged as explained in "CHARGING METHOD". If the battery is overcharged, the electrolyte level will drop considerably. Therefore, take special care when charging the battery.

WARNING _____

Battery electrolyte is dangerous; it contains sulfuric acid which is poisonous and highly caustic.

- Always follow these preventive measures:
- Avoid bodily contact with electrolyte as it can cause severe burns or permanent eye injury.
- Wear protective eye gear when handling or working near batteries.

Antidote (EXTERNAL):

- SKIN - Flush with water.
- EYES - Flush with water for 15 minutes and get immediate medical attention.

Antidote (INTERNAL):

- Drink large quantities of water or milk followed with milk of magnesia, beaten egg or vegetable oil. Get immediate medical attention.




- Batteries generate explosive hydrogen gas. Always follow the following preventive measures:
- Charge batteries in a well-ventilated area.
- Keep batteries away from fire, sparks or open flames (e.g., welding equipment, lighted cigarettes, etc.)
- DO NOT SMOKE when charging or handling batteries.

KEEP BATTERIES AND ELECTROLYTE OUT OF REACH OF CHILDREN.

1. Remove:
 - Side cover (right)
 - Cover (battery case)
 Refer to "SIDE COVER, SEAT AND FUEL TANK" section.
2. Disconnect:
 - Battery leads

CAUTION

Disconnect the negative lead ① first and then disconnect the positive lead ②.



3. Remove:
 - Battery
4. Check:
 - Battery condition



Battery condition checking steps:

- Connect a digital volt meter to the battery terminals.



Tester (+) lead → Battery (+) terminal
 Tester (-) lead → Battery (-) terminal

NOTE:

The charge state of an MF battery can be checked by measuring the open-circuit voltage (i.e. the voltage when the positive terminal is disconnected).



Open circuit voltage	Charging time
12.8 V or more	No charging is necessary.



- Check the condition of the battery using the charts.

Example:

Open-circuit voltage = 12.0V

Charging time = 6.5 hours


Charge condition of the battery = 20 ~ 30%

5. Charging method for MF batteries


CAUTION:

- If it is impossible to set the standard charging current, be careful not to overcharge.
- When charging the battery, be sure to remove it from the motorcycle. (If charging has to be done with the battery mounted on the motorcycle, be sure to disconnect the wire at the negative terminal.)
- Never remove the sealing caps of an MF battery.
- Make sure that the charging clips are in full contact with the terminal and that they are not shorted together. (A corroded clip on the charger may cause the battery to generate heat in the contact area. A weak clip spring may cause sparks.)
- Before removing the clips from the battery terminals, be sure to turn off the charger's power switch.
- The open-circuit voltage variation for the MF battery after charging is shown below. As shown in the figure, the open-circuit voltage stabilizes about 30 minutes after charging has been completed.
- Therefore, wait 30 minutes after charging is completed before measuring the open-circuit voltage.

Charging method using a variable-current (voltage) type charger



Charging method using a constant-voltage type charger



Charging method using a constant-current type charger

This type charger cannot charge the MF battery.

6. Inspect:
 - Battery terminals
 - Dirty terminal → Clean with wire brush.
 - Poor connection → Correct.

NOTE: _____

After cleaning the terminals, grease them lightly.

7. Install:
 - Battery
8. Connect:
 - Battery leads

CAUTION: _____

Connect the positive lead first and then connect the negative lead.

9. Install:
 - Side cover (right)
 - Refer to "SEAT, SIDE COVER AND FUEL TANK" section.

AG305010

FUSE INSPECTION

CAUTION: _____

Always turn off the main switch when checking or replacing the fuse. Otherwise, a short circuit may occur.

1. Remove:
 - Side cover (left, for main fuse)
 - Side cover (right, for terminal fuse)
 - Refer to "SIDE COVER, SEAT AND FUEL TANK" section.



2. Inspect:
 - Fuse
 - A** Fuse (main)
 - B** Fuse (auxiliary DC terminal)


Inspection steps:

- Connect the Pocket tester to the fuse and check it for continuity.

NOTE: _____

Set the tester selector to "Ω×1" position.



	Pocket tester: 90890-03112
---	---------------------------------------

- If the tester is indicated at ∞. Replace the fuse.



3. Replace:
 - Blown fuse

Replacement steps:

- Turn off the main switch.
- Install a new fuse with the proper current rating.

Main fuse side:



- Turn on switches to verify operation of related electrical devices.
- If the fuse blows again immediately, check the electrical circuit.

Terminal fuse side:

- Remove the cap ① and connect the pocket tester to the terminal ② on the front carrier.

NOTE:

Set the tester selector to "DC20V" position.



- Turn on the main switch and start the engine. Check for DC voltage output from the terminal.
- If the fuse blows again immediately or no voltage output, check the electrical circuit. Refer to "LIGHTING SYSTEM" section in CHAPTER 7.

WARNING


Never use a fuse with a rating other than that specified. Never use other materials in place of a fuse. An improper fuse may cause extensive damage to the electrical system, malfunction of lighting and ignition systems and could possibly cause a fire.

4. Install:
 - Side covers (left and right)
Refer to "SIDE COVER, SEAT AND FUEL TANK" section.

EB305022

HEADLIGHT BEAM ADJUSTMENT

1. Adjust:
 - Headlight beam (vertical)
Loosen the bolt ① and adjust the head light unit.






EB400000

ENGINE OVERHAUL

ENGINE REMOVAL


EXHAUST PIPE, STARTING MOTOR AND WIRE READ



Order	Job name/Part name	Q'ty	Remarks
	Exhaust pipe, starting motor and wire read removal		Remove the parts in order.
	Side cover, seat and fuel tank		Refer to "SIDE COVER, SEAT AND FUEL TANK" section in CHAPTER 3.
1	Foot rest (right)	1	
2	Brake pedal	1	
3	Protector (exhaust pipe)	1	
4	Exhaust pipe Assembly	1	
5	Gasket (exhaust pipe)	1	
6	Gasket (muffler)	1	
7	Battery negative lead	1	
8	Battery/positive lead	1	
9	Starting motor lead	1/1	
10	Starting motor	1	NOTE:
11	CDI magneto couplers	1	Disconnect the couplers.
12	Plug cap	1	Reverse the removal procedure for installation.




CARBURETOR, CLUTCH CABLE AND DRIVE CHAIN



Order	Job name/Part name	Q'ty	Remarks
	Carburetor, clutch cable and drive chain removal		Remove the parts in order.
	Carburetor		Refer to "CARBURETOR" section in CHAPTER 5.
1	Clutch cable	1	NOTE: Disconnect.
2	Crankcase breather hose	1	
3	Foot rest (left)	1	
4	Shift pedal	1	
5	Fitting plate	1	
6	Drive sprocket cover	1	
7	Rear wheel axle nut/ drive sprocket shaft nut	1/1	NOTE: Loosen the axle nut, drive sprocket shaft nut and slacken the drive chain.
8	Sprocket holder	1	
9	Drive sprocket/drive chain	1/1	Reverse the removal procedure for installation.




ENGINE



Order	Job name/Part name	Q'ty	Remarks
	Engine removal		Remove the parts in order. ⚠WARNING Securely support the motorcycle so there is no danger of it falling over.
1	Horn	1	
2	Engine stay (top)	1	
3	Engine guard	1	
4	Front engine stay	1	
5	Swingarm pivot shaft	1	
6	Engine mount bolt (rear under)	1	
7	Engine	1	Reverse the removal procedure for installation.




**CYLINDER HEAD
CAM SPROCKET COVER**








Order	Job name/Part name	Q'ty	Remarks
	Cam sprocket cover removal		Remove the parts in order.
	Side cover, seat and fuel tank		Refer to "SIDE COVER, SEAT AND FUEL TANK REMOVAL" section in CHAPTER 3.
	Exhaust pipe assembly		Refer to "ENGINE REMOVAL" section.
	Carburetor assembly		Refer to "CARBURETOR" section in CHAPTER 5.
	Engine stay (top)		Refer to "ENGINE REMOVAL" section.
1	Spark plug	1	
2	Cam sprocket cover/O-ring	1/1	
3	Valve cover (intake side)/O-ring	1/1	
4	Valve cover (exhaust side)/O-ring	1/1	
5	Carburetor joint/O-ring	1/1	
6	Timing mark cap/O-ring	1/1	
7	Center cap/O-ring	1/1	
			Reverse the removal procedure for installation.



CYLINDER HEAD



Order	Job name/Part name	Q'ty	Remarks
	Cylinder head removal		Remove the parts in order.
1	Ignition coil	1	
2	Timing chain tensioner assembly	1	
3	Gasket (timing chain tensioner)	1	
4	Cam sprocket/Timing chain	1	Refer to "CYLINDER HEAD REMOVAL/INSTALLATION" section.
5	Cylinder head	1	
6	Dowel pins	3	
7	Gasket	1	Refer to "CYLINDER HEAD INSTALLATION" section.
8	Cylinder head gasket	1	Reverse the removal procedure for installation.



T401030

CYLINDER HEAD REMOVAL

1. Align:

- Slit (a) on the magneto
(with stationary pointer (b) on the crank case cover)

NOTE: _____

Turn the crank shaft counterclockwise with a wrench and align the "I" mark (c) with the cylinder head match mark (d) when the piston is at TDC on the compression stroke.

2. Loosen:

- Bolt (cam sprocket) (1)

NOTE: _____

Loosen the bolt while holding the magneto mounting bolt with a wrench.

3. Remove:

- Cam sprocket bolt
- Cam sprocket (1)
- Timing chain (2)

NOTE: _____



Fasten a safety wire (a) to the timing chain to prevent it from falling into the crankcase.

4. Remove:

- Cylinder head

NOTE: _____

- Loosen the nuts in their proper loosening sequence.
- Start by loosening each nut 1/2 turn until all are loose.



YP402000

CYLINDER HEAD INSPECTION

1. Eliminate:
 - Carbon deposits (from combustion chambers)
 Use a rounded scraper.

NOTE: _____

Do not use a sharp instrument to avoid damaging or scratching:

- Spark plug threads
- Valve seats

2. Inspect:
 - Cylinder head
 - Scratches/damage → Replace.
3. Measure:
 - Cylinder head warpage
 - Out of specification → Resurface.



**Cylinder head warpage:
Less than 0.03 mm**

Warpage measurement and resurfacement steps:

- Place a straightedge and a feeler gauge across the cylinder head.
- Measure the warpage.
If the warpage is out of specification, resurface the cylinder head.
- Place a 400 ~ 600 grit wet abrasive paper on the surface plate, and resurface the head using a figure-eight sanding pattern.


NOTE: _____


Rotate the cylinder head several times for an even resurfacement.

EB402080

TIMING CHAIN TENSIONER INSPECTION

1. Check:
 - One way cam operation
 - Unsmooth operation → Replace.






AG404193

CYLINDER HEAD INSTALLATION

1. Install:

- Dowel pins ①
- Gasket ② **New**
- Gasket (cylinder head) ③ **New**




2. Install:

- Cylinder head

	M8 (1~4)	22 Nm (2.2 m•kg)
	M8 (5~6)	20 Nm (2.0 m•kg)

NOTE:

- Apply engine oil onto the nut threads.
- Tighten the bolts starting with the lowest numbered one.




3. Install:

- Cam sprocket
- Timing chain


Installing steps:

- Turn the crank shaft counterclockwise until the slit ① matches the stationary pointer ②.
- Align the dowel pin ③ on the camshaft with the stationary pointer ④ on the cylinder head.
- Align the "I" mark ⑤ on the cam sprocket with the stationary pointer ⑥ on the cylinder head.
- Fit the timing chain ⑦ onto cam sprocket ⑧ and install the cam sprocket on the camshaft.






NOTE:

When installing the cam sprocket, keep the timing chain as tight as possible on the exhaust side.



CAUTION:

Do not turn the crankshaft during installation of the camshaft. Damage or improper valve timing will result.




- Remove the safety wire from the timing chain.

4. Install:


- Gasket
- Timing chain tensioner

Installation steps:

- While lightly pressing the timing chain tensioner rod by hand, use a thin screwdriver ① and wind the tensioner rod up fully clockwise.
- With the tensioner rod fully wound, install the gasket and the chain tensioner ②, and tighten the bolt ③ to the specified torque.

	Timing chain tensioner: 10 Nm (1.0 m·kg)
---	---

- Remove the screwdriver, make sure the tensioner rod comes out and tighten the gasket and cap bolt to the specified torque.

	Cap bolt (timing chain tensioner): 7 Nm (0.7 m·kg)
---	---

5. Tighten:

- Bolt (camshaft)

	60 Nm (6.0 m·kg)
---	-------------------------

NOTE: _____

Install the bolt while holding the magneto mounting bolt with a wrench.

6. Check:


- Valve timing
Out of alignment → Adjust.
Refer to above steps 3.

7. Check:

- Valve clearance
Out of specification → Adjust.
Refer to "VALVE CLEARANCE ADJUSTMENT" section in CHAPTER 3.


8. Install:

- O-ring
- Cam sprocket cover



	7 Nm (0.7 m·kg)
---	------------------------



CAM SHAFT AND ROCKER ARMS



Order	Job name/Part name	Q'ty	Remarks
	Cam shaft and rocker arm removal		Remove the parts in order.
	Cylinder head		Refer to the "CYLINDER HEAD" section.
1	Lock washer	1	Refer to the "CAMSHAFT AND ROCKER ARM INSTALLATION" section.
2	Plate	1	
3	Collar	1	
4	Cam shaft	1	Refer to the "ROCKER ARM AND ROCKER ARM SHAFT REMOVAL/CAMSHAFT AND ROCKER ARM INSTALLATION" section.
5	Rocker arm shaft (intake side)	1	
6	Rocker arm shaft (exhaust side)	1	
7	Rocker arms	2	
8	O-ring	1	
9	Nut/Adjusters	2/2	Reverse the removal procedure for installation.



SR*****

ROCKER ARM AND ROCKER ARM SHAFT REMOVAL

- Remove:
 - Camshaft ①
 - Collar (camshaft) ②

NOTE: _____
Use 10 mm bolt ③ to remove the camshaft.

- Remove:
 - Rocker arm shaft (intake)
 - Rocker arm shaft (exhaust)

NOTE: _____
Attach a rocker arm shaft puller bolt ① and weight ② to the rocker arm shaft and slide out the shaft.




Rocker arm shaft puller bolt:
90890-01083
Weight:
90890-01084

YP402052

CAMSHAFT INSPECTION

- Inspect:
 - Cam lobes
Pitting/Scratches/Blue discoloration→ Replace.
- Measure:
 - Cam lobes length [A] and [B].
Out of specification→Replace.



Cam lobes length:




Intake:

- [A] 36.54~36.64 mm
<Limit: 36.48 mm>
- [B] 30.15~30.25 mm
<Limit: 30.1 mm>

Exhaust:

- [A] 36.58~36.68 mm
<Limit: 36.49 mm>
- [B] 30.27~30.37 mm
<Limit: 30.2 mm>

- Inspect:
 - Camshaft oil passage
Stuffed→ Blow out oil passage with compressed the air.



YP402060


ROCKER ARMS AND ROCKER ARM SHAFTS INSPECTION

1. Inspect:


- Rocker arm shafts
 - Rocker arms
- Wear/Pitting/Scratches/Blue discoloration
→ Replace.

Inspection steps:

- Inspect the two contact areas on the rocker arms for signs of unusual wear.
- Rocker arm shaft hole.
- Cam-lobe contact surface.
Excessive wear → Replace.
- Inspect the surface condition of the rocker arm shafts.
Pitting/scratches/blue discoloration → Replace or check lubrication.
- Measure the inside diameter of the rocker arm holes.
Out of specification → Replace.

	<p>Inside diameter (rocker arm): 12.000~12.018 mm <Limit: 12.036 mm></p>
---	---

- Measure the outside diameter of the rocker arm shafts.
Out of specification → Replace.


	<p>Outside diameter (rocker arm shaft): 11.981~11.991 mm <Limit: 11.950 mm></p>
---	--

SR*****

CAMSHAFT AND ROCKER ARM INSTALLATION

1. Lubricate:

- Camshaft

	<p>Camshaft: Engine oil</p>
	<p>Camshaft bearing: Engine oil</p>



2. Apply:
 - Molybdenum disulfide oil
(onto the rocker arm and rocker arm shaft)





3. Install:
 - Rocker arm
 - Rocker arm shaft ①

NOTE: _____

- Apply engine oil onto the outside of the rocker arm shaft and apply molybdenum disulfide oil onto the inside of the rocker arm.
- Install the rocker arm shaft (intake), match the cut away (a) and bolt hole (b).

CAUTION: _____


- Make sure that the rocker shaft install direction.
- Install the rocker arm shaft into the thread side for the out.



4. Install:
 - Camshaft ①
 - Collar ②

NOTE: _____

- Apply engine oil onto the cam profile face and journal face.
- Install the camshaft, match the dowel pin (a) and cylinder head mark (b).




5. Install:
 - Plate ①
 - Lock washer ② **New**
 - Bolt ③

8 Nm (0.8 m•kg)


NOTE: _____

After tighten the bolt, bend the end of the rock washer.

VALVES AND VALVE SPRINGS



Order	Job name/Part name	Q'ty	Remarks
	Valves and valve springs removal		Remove the parts in order.
	Cylinder head		Refer to "CYLINDER HEAD" section.
	Rocker arm, Camshaft		Refer to "CAMSHAFT AND ROCKER ARMS" section.
1	Valve cotters	4	Refer to "VALVES AND VALVE SPRINGS REMOVAL/INSTALLATION" section.
2	Spring retainers	2	Refer to "VALVES AND VALVE SPRINGS INSTALLATION" section.
3	Valve springs (inner)	2	
4	Valve springs (outer)	2	
5	Valve (intake)	1	
6	Valve (exhaust)	1	
7	Valve guides (stem seal)	2	
8	Spring seats	2	Reverse the removal procedure for installation.



YP401150

VALVES AND VALVE SPRINGS REMOVAL

- Remove:
 - Valve cotter pins ①

NOTE: Attach a valve spring compressor and attachment ② between the valve spring retainer and cylinder head to remove the valve cotter pins.


CAUTION:

Do not compress so much as to avoid damage to the valve spring.



Valve spring compressor:
90890-04019

Valve spring compressor attachment:
90890-04108



EB402010

VALVES AND VALVE GUIDES INSPECTION

- Measure:
 - Stem-to-guide clearance

Stem-to-guide clearance =
 valve guide inside diameter (a) -
 valve stem diameter (b)

Out of specification → Replace the valve guide.



Clearance (stem to guide):

Intake:
0.010 ~ 0.037 mm

<Limit: 0.08 mm>


Exhaust:
0.025 ~ 0.052 mm

<Limit: 0.10 mm>



- Replace:
 - Valve guide

Replacement steps:


NOTE: Heat the cylinder head in an oven to 100°C to ease guide removal and installation and to maintain correct fit.



- Remove the valve guide using a valve guide remover ①.




- Install the new valve guide using a valve guide installer ② and valve guide remover ①.
- After installing the valve guide, bore the valve guide using a valve guide reamer ③ to obtain proper stem-to-guide clearance.


	Valve guide remover (6 mm): 90890-04064
	Valve guide installer (6 mm): 90890-04065
	Valve guide reamer (6 mm): 90890-04066


NOTE: _____
 Reface the valve seat after replacing the valve guide.

- Eliminate:
 - Carbon deposits (from the valve face)
- Inspect:
 - Valve face
Pitting/wear → Grind the face.
 - Valve stem end
Mushroom shape or diameter larger than the body of the stem → Replace.




- Measure:
 - Margin thickness ①
Out of specification → Replace.

	Margin thickness:
	Intake
	0.8 ~ 1.2 mm
	Exhaust
	0.8 ~ 1.2 mm



- Measure:
 - Runout (valve stem)
Out of specification → Replace.


	Runout:
	Less than 0.03 mm


NOTE: _____
 • Always replace the guide when installing a new valve.
 • Always replace the oil seal if the valve is removed or replaced.


EB402020

VALVE SEATS INSPECTION

1. Eliminate:
 - Carbon deposits
(from the valve face and valve seat)
2. Inspect:
 - Valve seats
Pitting/wear → Reface the valve seat.
3. Measure:
 - Valve seat width (a)
Out of specification → Reface the valve seat.



	Valve seat width:
	Intake:
	0.9~1.1 mm <Limit: 1.6 mm>
	Exhaust:
	0.9~1.1 mm <Limit: 1.6 mm>



Measurement steps:

- Apply Mechanic's blueing dye (Dykem) ① to the valve face.
- Install the valve into the cylinder head.
- Press the valve through the valve guide and onto the valve seat to make a clear pattern.
- Measure the valve seat width. Where the valve seat and valve face made contact, blueing will have been removed.
- If the valve seat is too wide, too narrow, or the seat is not centered, the valve seat must be replaced.

EB402020

4. Lap:
 - Valve face
 - Valve seat

NOTE: _____


After replacing the valve seat, valve and valve guide, the valve seat and valve face should be lapped.


Lapping steps:

- Apply a coarse lapping compound (a) to the valve face.


CAUTION: _____

Do not let compound enter the gap between the valve stem and the guide.





- Apply molybdenum disulfide oil to the valve stem.
- Install the valve into the cylinder head.




- Turn the valve until the valve face and valve seat are evenly polished, then clean off all compound.

	Valve lapper: 90890-04101
--	--

NOTE: _____


For best lapping results, lightly tap the valve seat while rotating the valve back and forth between your hand.



- Apply a fine lapping compound to the valve face and repeat the above steps.

NOTE: _____

Make sure to clean off all compound from the valve face and valve seat after every lapping operation.




- Apply Mechanic's blueing dye (Dykem) (b) to the valve face.
- Install the valve into the cylinder head.
- Press the valve through the valve guide and onto the valve seat to make a clear pattern.
- Measure the valve seat width (c) again.

EB404032

VALVES AND VALVE SPRINGS INSTALLATION

1. Deburr:

- Valve stem end
Use an oil stone to smooth the stem end.



2. Apply:
 - Molybdenum disulfide oil
(onto the valve stem ③ and oil seal ②)






3. Install:
 - Valve spring seat ①
 - Valve stem seal ② **New**
 - Valve ③
(into the cylinder head)
 - Valve spring (inner) ④
 - Valve spring (outer) ⑤
 - Spring retainer ⑥

NOTE: _____
Install the valve spring with the larger pitch
① facing upwards.

② Smaller pitch

4. Install:
 - Valve cotters ①

NOTE: _____
Install the valve cotters while compressing
the valve spring with a valve spring com-
pressor and attachment ②.




5. Secure the valve cotters onto the valve stem by tapping lightly with a piece of wood.



CAUTION: _____
Do not hit so much as to damage the valve.



CYLINDER AND PISTON



Order	Job name/Part name	Q'ty	Remarks
	Cylinder and piston removal		Remove the parts in order. Refer to "CYLINDER HEAD" section.
	Cylinder head		
1	Timing chain guide (exhaust side)	1	
2	Cylinder/O-ring	1/1	
3	O-ring	1	Refer to "PISTON RINGS, PISTON AND CYLINDER INSTALLATION" section.
4	Dowel pins	2	
5	Cylinder gasket	1	
6	Piston pin clips	2	Refer to "PISTON AND PISTON RINGS REMOVAL" section.
7	Piston pin	1	
8	Piston	1	Refer to "PISTON RINGS, PISTON AND CYLINDER INSTALLATION" section.
9	Piston ring set	1	
			Reverse the removal procedure for installation.



yp*****

PISTON AND PISTON RINGS REMOVAL

1. Remove:

- Piston pin clip ①
- Piston pin ②
- Piston ③

NOTE: _____

Before removing the piston pin clip, cover the crankcase opening with a clean towel or rag to prevent the circlip from falling into the crankcase cavity.

2. Remove:

- Top ring
- 2nd ring
- Oil ring

NOTE: _____

When removing the piston ring, open the end gap of the ring by fingers, and push up the other side of the ring.

EB402100

CYLINDER AND PISTON INSPECTION

1. Inspect:

- Cylinder and piston walls
Vertical scratches → Rebore or replace the cylinder and the piston.

2. Measure:

- Piston-to-cylinder clearance


Measurement steps:

1st step:

- Measure the cylinder bore "C" with a cylinder bore gauge.
① 40 mm from the top of the cylinder.

NOTE: _____

Measure the cylinder bore "C" in parallel to and at right angles to the cylinder mating surface. Then, find the average of the measurements.



304-011



Cylinder bore "C":
66.97~67.02 mm

<Limit:>
67.1 mm

$$C = \frac{X + Y}{2}$$

- If out of specification, rebores or replace the cylinder, and replace the piston and piston rings as a set.

2nd step:

- Measure the piston skirt diameter "P" with a micrometer.

(a) 7.5 mm from from the piston bottom edge.

	Piston size P
Standard	66.935 ~ 66.985 mm
Oversize 2	0.50 mm
Oversize 4	1.00 mm

- If out of specification, replace the piston and the piston rings as a set.

3rd step:


- Calculate the piston-to-cylinder clearance using the following formula:


Piston-to-cylinder clearance =
Cylinder bore "C" -
Piston skirt diameter "P"



Piston-to-cylinder clearance:
0.025 ~ 0.045 mm

- If out of specification, rebores or replace the cylinder, and replace the piston and piston rings as a set.





EB402110

PISTON RING INSPECTION

1. Measure:

- Side clearance

Out of specification → Replace the piston and the piston rings as a set.

NOTE:

Eliminate the carbon deposits from the piston ring grooves and rings before measuring the side clearance.


**Side clearance:**

Top ring: <Limit>

0.03 ~ 0.07 mm <0.15 mm>

2nd ring: <Limit>

0.02 ~ 0.06 mm < 0.15 mm>



307 027

2. Position:

- Piston ring
(into the cylinder)

NOTE:

Push the ring with the piston crown so that the ring will be at a right angle to the cylinder bore.

① 40 mm

3. Measure:

- End gap

Out of specification → Replace.

NOTE:

You cannot measure the end gap on the expander spacer of the oil ring. If the oil ring rails show excessive gap, replace all three rings.

**End gap:**

Top ring: <Limit>

0.15 ~ 0.35 mm <0.60 mm>

2nd ring: <Limit>

0.15 ~ 0.35 mm <0.60 mm>

Oil ring:

0.3 ~ 0.9 mm




EB402120

PISTON PIN INSPECTION

1. Inspect:
 - Piston pin
Blue discoloration/grooves → Replace, then inspect the lubrication system.
2. Measure:
 - Piston pin-to-piston clearance

Measurement steps:

- Measure the piston pin outside diameter (a).
If out of specification, replace the piston pin.



Outside diameter (piston pin):
15.991 ~ 16.000 mm

- Measure the piston inside diameter (b).
- Calculate the piston pin-to-piston clearance using the following formula:

Piston pin-to-piston clearance =
Bore size (piston pin) (b) -
Outside diameter (piston pin) (a)

- If out of specification, replace the piston.

Clearance (piston pin-to-piston):
0.002 ~ 0.022 mm



EB404184


PISTON RINGS, PISTON AND CYLINDER INSTALLATION

1. Install:
 - Top ring ①
 - 2nd ring ②
 - Side rails (oil ring) ③
 - Expander spacer (oil ring) ④

NOTE:

- Make sure to install the piston rings so that the manufacturer's marks or numbers are located on the upper side of the rings.
- Lubricate the pistons and piston rings liberally with engine oil.





2. Install:
 - Piston ①
 - Piston pin ②
 - Piston pin clip ③ **New**


NOTE:

- Apply engine oil onto the piston pins.
- The "→" mark (a) on the piston must face the exhaust side of the cylinder.
- Before installing the piston pin clip, cover the crankcase opening with a clean rag to prevent the piston pin clip from falling into the crankcase.
- Make sure to install each piston in its respective cylinder.

3. Install:
 - O-ring **New**
 - Dowel pins

4. Position:
 - Piston rings

NOTE:
Offset the piston ring end gaps as shown.



- (a) Top ring end
- (b) Oil ring end (lower)
- (c) Oil ring end (upper)
- (d) 2nd ring end


5. Lubricate:
 - Piston outer surface
 - Piston ring
 - Cylinder inner surface



6. Install:
 - Gasket (cylinder) ① **New**
 - Cylinder ②


NOTE:

- Install the cylinder with one hand while compressing the piston rings with the other hand.
- Pass the timing chain and timing chain guide (exhaust side) through the timing chain cavity.






CLUTCH
CRANKCASE COVER (RIGHT)




Order	Job name/Part name	Q'ty	Remarks
	Crankcase cover (right) removal Drain the engine oil		Remove the parts in order. Refer to "ENGINE OIL REPLACEMENT" section in CHAPTER 3.
	Clutch cable		Refer to "CLUTCH ADJUSTMENT" section in CHAPTER 3.
1	Kick crank	1	
2	Rear brake rod	1	Refer to "REAR WHEEL, REAR BRAKE, SPROCKET AND DRIVE CHAIN" section in CHAPTER 6.
3	Foot rest (right)	1	
4	Rear brake pedal	1	
5	Crankcase cover (right)	1	
6	Crankcase cover gasket (right)	1	
7	Dowel pins	2	Reverse the removal procedure for installation.




CLUTCH



Order	Job name/Part name	Q'ty	Remarks
	Clutch removal		Remove the parts in order.
	Sprocket cover		Refer to "ENGINE REMOVAL" section.
1	Clutch springs	4	Refer to "CLUTCH REMOVAL/INSTALLATION" section.
2	Pressure plate	1	
3	Nut/Washer	1/1	
4	Push plate	1	
5	Push rod #1/O-ring	1/1	
6	Clutch plates	4	
7	Friction plates	5	
8	Cushion spring	1	
9	Nut/Lock washer	1/1	
10	Clutch boss	1	
11	Plate washer	1	
12	Primary driven gear	1	



Order	Job name/Part name	Q'ty	Remarks
13	Ball	1	Refer to "CLUTCH INSTALLATION" section.
14	Push rod #2	1/1	
15	Push lever screw/Gasket	1	Refer to "CLUTCH INSTALLATION" section.
16	Push lever axle	1	
17	Torsion spring	1	
18	Circlip	1	Reverse the removal procedure for installation.
19	Oil seal	1	



SR401061

CLUTCH REMOVAL

1. Remove:

- Nut ① (clutch boss)
- Lock washer ②
- Clutch boss ③

Straighten the lock washer tab ④.

NOTE:

Loosen the clutch boss nut ① while holding the clutch boss with a clutch holding tool ④.



Clutch holding tool:
90890-04086

SR402181


CLUTCH INSPECTION

1. Inspect:

- Friction plates
Damage/wear → Replace the friction plates as a set.

2. Measure:

- Friction plate thickness
Out of specification → Replace the friction plates as a set.
Measure at four places.




Thickness (friction plate):
2.9 ~ 3.1 mm
<Limit: 2.8 mm>

3. Inspect:

- Clutch plates
Damage → Replace the clutch plates as a set.

4. Measure:


- Clutch plate warpage
Out of specification → Replace the clutch plates as a set.
Use a surface plate and a feeler gauge ①.



Warp limit (clutch plate):
Less than 0.2 mm

5. Inspect:

- Clutch springs
Damage → Replace the clutch springs as a set.




6. Measure:

- Free length (clutch spring) ①
Out of specification → Replace the clutch springs as a set.

**Free length (clutch spring):**

37.3 mm

<Limit: 35.3 mm>




7. Inspect:

- Dogs on the primary driven gear ①
Scoring/wear/damage → Deburr or replace.
- Clutch boss splines ②
Scoring/wear/damage → Replace clutch boss.

NOTE:

Scoring on the clutch housing dogs and the clutch boss splines will cause erratic operation.




SR*****

PUSH ROD INSPECTION

1. Inspect:

- Push rod #1 ①
- Ball ②
- Push rod #2 ③
Wear/crack/damage → Replace.




AG*****

CLUTCH INSTALLATION

1. Install:


- Push lever axle ①
- Gasket ② **New**
- Screw ③

12 Nm (1.2 m·kg)



2. Install:

- Primary driven gear ①
- Plate washer ②
- Clutch boss ③



3. Install:
- Lock washer ① **New**
 - Nut ② (clutch boss)


70 Nm (7.0 m•kg)

NOTE:

Install the clutch boss nut ② while holding the clutch boss with a clutch holding tool ③.




Clutch holding tool:
90890-04086




4. Bend:
- Lock washer tab
(along a flat side of the end)
5. Install:
- Friction plate ①
 - Clutch plate ②
 - Cushion spring ③

NOTE:

- Install the clutch plates and friction plates alternately on the clutch boss, starting with a friction plate and ending with a friction plate.
- Install the cushion spring must be placed on inside of the third friction plate.
- Coat all clutch and friction plates with engine oil before installation.



6. Install:
- Push rod #2
 - Ball
7. Install:
- Push rod #1 ①
 - O-ring ② **New**
 - Push Plate ③
 - Plate washer ④
 - Nut ⑤ (push rod #1)




8. Install:
- Pressure plate ①
 - Compression springs ②
 - Bolts ③ (clutch springs)

6 Nm (0.6 m•kg)


NOTE:

Tighten the clutch spring bolts in stage, using a crisscross pattern.



9. Check:
- Push lever position
Push the push lever assembly in the arrow direction and make sure that match marks are aligned → Adjust.

- Ⓐ Match mark on the push lever assembly
- Ⓑ Match mark on the crankcase



10. Adjust:
- Push lever position
- *****

Adjustment steps:

- Loosen the locknut ①.
- Turn the adjuster ② clockwise or counter-clockwise to match alignment marks.
- Hold the adjuster to prevent it from moving and tighten the locknut to specification.


CAUTION:

Take care not to overtighten the adjuster ② and to remove the free play between both push rods.





- Tighten the lock nut ①. **8 Nm (0.8 m·kg)**



KICK STARTER



Order	Job name/Part name	Q'ty	Remarks
	Kick starter removal		Remove the parts in order.
	Crankcase cover		Refer to "CLUTCH" section.
	Clutch		
1	Kick starter	1	Refer to "KICK STARTER INSTALLATION" section
2	Kick idle gear	1	Reverse the removal procedure for installation.
	Kick starter disassembly		Disassemble the parts in order.
①	Washer/special washer	1/1	
②	Circlip/Cover (spring)	1/1	
③	Spring	1	
④	Washer	1	
⑤	Kick gear/Clip	1/1	
⑥	Kick axle	1	Reverse the disassemble procedure for assembly.



AG*****

KICK STARTER INSPECTION

1. Inspect:

- Gear teeth (kick gear) ①
 - Gear teeth (kick idle gear) ②
- Wear/damage → Replace.

2. Inspect:

- Torsion spring
- Wear/crack → Replace.

3. Measure:

- Kick clip friction force (torsion spring ①)
- Out of specification → Replace.
Use a spring gauge.



Kick clip friction force:
0.65 ~ 1.05 kg

AG*****

KICK STARTER INSTALLATION

1. Install:


- Kick axle assembly ①
- Kick gear clip ②
- Torsion spring ③
- Kick idle gear

NOTE:


Turn the torsion spring clockwise and hook into the proper hole (a) in the crank case.




OIL PUMP



Order	Job name/Part name	Q'ty	Remarks
	Oil pump removal		Remove the parts in order.
	Clutch		Refer to "CLUTCH" section.
	Kick starter		Refer to "KICK STARTER" section.
1	Nut (primary drive gear)	1	Refer to "PRIMARY DRIVE GEAR REMOVAL/INSTALLATION" section.
2	Lock washer	1	
3	Primary drive gear	1	
4	Oil pump cover	1	Refer to "OIL PUMP INSTALLATION" section.
5	Oil pump assembly	1	
6	Gasket (oil pump cover)	1	Reverse the removal procedure for installation.



Order	Job name/Part name	Q'ty	Remarks
	Oil pump disassembly		Disassemble the parts in order.
①	Oil pump housing	1	
②	Dowel pin	1	
③	Oil pump driven gear	1	
④	Dowel pins	2	
⑤	Inner rotor	1	
⑥	Outer rotor	1	
⑦	Housing	1	Reverse the disassembly procedure for assembly.



SR401070

PRIMARY DRIVE GEAR REMOVAL

1. Remove:


NOTE: _____

Straighten the lock washer tab.

- Nut (primary drive gear) ①
- Lock washer ②
- Primary drive gear ③

NOTE: _____

Place a folded aluminium plate or copper washer ① between the teeth of the balancer drive gear ④ and balancer driven gear ⑤.



T402140

OIL PUMP INSPECTION

1. Measure:

- Tip clearance [A]
(between the inner rotor ① and the outer rotor ②)
- Side clearance [B]
(between the outer rotor ② and the pump housing ③)
Out of specification → Replace the oil pump assembly.
- Housing and rotor clearance [C]
(between the pump housing ③ and the rotors ①, ②.)
Out of specification → Replace the oil pump assembly.

**Tip clearance [A]:**


0.15 mm or less <Limit: 0.15 mm>

Side clearance [B]:

0.10 ~ 0.15 mm <Limit: 0.35 mm>

Housing and rotor clearance [C]:

0.03 ~ 0.09 mm <Limit: 0.14 mm>




SR*****

**OIL DELIVERY PASSAGE INSPECTION
(CRANK CASE COVER (right))**

1. Check:

- Oil delivery passage
Blockage → Blow by the compressed air.



SR404010


OIL PUMP INSTALLATION

1. Lubricate:

- Oil delivery passage (crankcase right)
- Oil pump assembly



Recommended lubricant :
Engine oil



SR404140

PRIMARY DRIVE GEAR INSTALLATION

1. Install:

- Primary drive gear ①
- Lock washer ② **New**
- Nut (primary drive gear) ③


50 Nm (5.0 m·kg)

NOTE:


- Place a folded aluminium plate or copper washer (a) between the teeth of the balancer drive gear (4) and balancer driven gear (5).
- Bend the lock washer tab, after tighten the nut flats.



BALANCER GEAR



Order	Job name/Part name	Q'ty	Remarks
	Balancer gear removal		Remove the parts in order.
	Clutch		Refer to "CLUTCH" section.
	Kick starter		Refer to "KICK STARTER" section
	Primary drive gear/oil pump		Refer to "OIL PUMP" section.
1	Nut/Lock washer	1/1	Refer to "BALANCER DRIVEN GEAR
2	Balancer driven gear	1	REMOVAL/BALANCER GEAR INSTALLA- TION" section.
3	Woodruff key	1	
4	Claw washer	1	
5	Balancer drive gear	1	Refer to "BALANCER DRIVE GEAR
6	Buffer boss	1	ASSEMBLY" section.
7	Compression springs	6	
8	Dowel pins	3	
9	Woodruff key	1	
10	Plate washer	1	Reverse the removal procedure for installation.



SR*****

BALANCER DRIVEN GEAR REMOVAL

1. Remove:


NOTE: _____

Straighten the lock washer tab.

- Nut (balancer driven gear) ①
- Lock washer ②
- Balancer driven gear ③

NOTE: _____

Place a folded aluminium plate or copper washer (a) between the teeth of the balancer drive gear ④ and balancer driven gear ③.




AG*****

BALANCER DRIVE GEAR INSPECTION

1. Inspect:

- Balancer drive gear ①
 - Buffer boss ②
 - Compression spring ③
 - Dowel pins ④
- Wear/Pitting/Scratches → Replace.



SR*****


BALANCER DRIVE GEAR ASSEMBLY

1. Assembly:

- Dowel pins ①
- Compression springs ②

NOTE: _____

Install the dowel pins and compression springs alternately as shown as.





2. Install:

- Buffer boss ①

NOTE: _____

Align the punched mark (a) on the buffer boss with the one on the balancer drive gear.



SR*****

BALANCER GEAR INSTALLATION

1. Install:

- Balancer driven gear ①

NOTE: _____

Install the balancer driven gear, then mesh the balancer driven gear match mark ① and balancer drive gear assembly match mark ②.

2. Install:


- Lock washer ① **New**
- Nut (balancer drive gear) ②

50 Nm (5.0 m·kg)
NOTE: _____


- Place a folded aluminium plate or copper washer ③ between the teeth of the balancer drive gear ③ and balancer driven gear ④.
- Bend the lock washer tab, after tighten the nut flats.




SHIFT SHAFT AND SEGMENT



Order	Job name/Part name	Q'ty	Remarks
	Shift shaft and segment removal		
	Clutch		Remove the parts in order. Refer to "CLUTCH" section.
	Kick starter		Refer to "KICK STARTER" section.
	Shift pedal		Refer to "ENGINE REMOVAL" section.
1	Shift shaft	1	Refer to "SHIFT SHAFT REMOVAL/ INSTALLATION" section.
2	Plate washer	1	
3	Torsion spring	1	
4	Stopper lever	1	
5	Plate washer	1	
6	Circlip	1	
7	Torsion spring	1	
8	Collar	1	
9	Tension spring	1	



Order	Job name/Part name	Q'ty	Remarks
10	Screw	1	Refer to "SEGMENT INSTALLATION" section.
11	Segment	1	
12	Dowel pins (short length)	4	
13	Dowel pin (long length)	1	Reverse the removal procedure for installation.




SR*****

SHIFT SHAFT REMOVAL

1. Remove:
 - Shift shaft assembly ①

NOTE: _____



Push the shift lever arm ② and the stopper lever ③ to the arrow direction and remove them from the segment.




T402200

SHIFT SHAFT INSPECTION

1. Inspect:
 - Stopper lever
 - Roller turns roughly → Replace.
 - Bends/damage → Replace.
2. Inspect:
 - Torsion springs (stopper lever and shift arm)
 - Wear/damage → Replace.



3. Inspect:
 - Shift shaft assembly ①
 - Shift lever ②
 - Bends/wear/damage → Replace.




SR*****

SEGMENT INSTALLATION

1. Install:
 - Segment ①
 - Dowel pins ② (short length)
 - Dowel pin ③ (long length)

NOTE: _____


Install the dowel pin ③ (long length) into the hole beside the match mark ④ position.



2. Install:
 •Segment ①


NOTE:

Fit the dowel pin ② (long length) on the segment to the locating hole ③ on the shift cam and install the segment.



3. Tighten:
 •Screw ①

12 Nm (1.2 m·kg)





SR*****

SHIFT SHAFT INSTALLATION

1. Install:
 •Shift shaft assembly

Installing steps:


- Set the stopper lever and return spring to the shift shaft.
- Mesh the stopper lever ① with the shift cam segment.
- Install the shift lever ② to the shift cam segment.
- After installing the shift shaft, check the shift cam for smooth operation by turning the shift shaft with your hand.



2. Check:
 •Shift lever ① position
 Gaps ③ and ④ are not equal → Replace the defective parts.




CDI MAGNETO AND STARTER CLUTCH
CRANKCASE COVER (LEFT)



Order	Job name/Part name	Q'ty	Remarks
	Crankcase cover (left) removal Drain the engine oil		Remove the parts in order. Refer to "ENGINE OIL REPLACEMENT" section in CHAPTER 3. Refer to "SIDE COVER, SEAT AND FUEL TANK" section in CHAPTER 3. Refer to "ENGINE REMOVAL" section.
	Side cover (left)		
	Fitting plate/drive sprocket cover CDI magneto lead couplers		
1	Neutral switch lead connector	1	NOTE: Disconnect.
2	Crankcase cover (left)	1	
3	Gasket	1	
4	Dowel pins	2	Reverse the removal procedure for installation.




PICKUP COIL AND STATOR COIL



Order	Job name/Part name	Q'ty	Remarks
	Pickup coil and stator coil removal		Remove the parts in order.
1	Clamp (stator coil)	1	
2	Clamp (pickup coil)	1	
3	Pickup coil	1	
4	Stator coil	1	Reverse the removal procedure for installation.





CDI MAGNETO AND STARTER CLUTCH



Order	Job name/Part name	Q'ty	Remarks
	CDI magneto and starter clutch removal		
1	Sprocket cover CDI magneto	1	Remove the parts in order. Refer to "ENGINE REMOVAL" section. Refer to "CDI MAGNETO REMOVAL/ INSTALLATION" section.
2	Idle shaft/collar	1	
3	Starter idle gear	1	
4	Woodruff key	1	
5	Starter wheel gear	1	Refer to "CDI MAGNETO INSTALLATION" section.
6	Shim	1	
7	Dowel pins (inner)	3	
8	Spring caps	3	Refer to "STARTER CLUTCH INSTALLA- TION" section.
9	Compression springs	3	
10	Dowel pins (outer)	3	
11	Starter clutch	1	Reverse the removal procedure for installation.

CDI MAGNETO AND STARTER CLUTCH

ENG



YP401081

CDI MAGNETO REMOVAL

- Remove:
 - Bolt ① (magneto)
 - Plain washer ②

NOTE:

- Loosen the bolt (magneto) ① while holding the rotor with a sheave holder ③.
- Do not allow the sheave holder to touch the projection on the magneto.



Sheave holder:
90890-01701

- Remove:
 - CDI magneto assembly ①
 - Woodruff key

NOTE:

Remove the magneto using sheave holder ②, rotor puller ③ and rotor puller attachment ④.



Rotor puller:
90890-01080
Rotor puller attachment:
90890-04052

SR402163



STARTER CLUTCH INSPECTION


- Check:
 - Starter clutch operation
Push the dowel pins to the arrow direction.
Unsmooth operation → Replace.

Checking steps:

- Hold the starter clutch.
- When turning the starter wheel gear clockwise ①, the starter clutch and the starter wheel gear should be engaged.
- If not, the starter clutch is faulty. Replace it.
- When turning the starter wheel gear counterclockwise ②, it should turn freely.
- If not, the starter clutch is faulty. Replace it.

- Inspect:
 - Dowel pins ①
 - Compression springs ②
 - Spring caps ③
 Wear/Damage → Replace.






3. Inspect:
 - Starter wheel gear (contacting surface)
 - Pitting/Wear/Damage → Replace.


SR*****

STARTER CLUTCH INSTALLATION



1. Install:
 - Starter clutch assembly ①
2. Unloosen the starter clutch assembly by using the center punch.


30 Nm (3.0 m·kg)




3. Install:
 - Compression springs ①
 - Spring caps ②
 - Dowel pins ③

YP404131

CDI MAGNETO INSTALLATION



1. Install:
 - Shim ①
 - Starter wheel gear ②
 - Woodruff key ③



2. Install:
 - CDI magneto assembly ①

NOTE:


- Clean the tapered portion of the crankshaft and the magneto hub.
- When installing the magneto rotor, make sure the woodruff key is properly seated in the key way of the crankshaft and the starter wheel gear ② rotate to the right.

CDI MAGNETO AND STARTER CLUTCH


ENG



G



3. Tighten:
• CDI magneto assembly ①

 **50 Nm (5.0 m·kg)**


NOTE: Tighten the bolt while holding the CDI magneto assembly with the sheave holder ②.




Sheave holder:
90890-01701



CRANK CASE AND CRANKSHAFT
CRANKCASE




Order	Job name/Part name	Q'ty	Remarks
	Crankcase separation		Remove the parts in order.
	Engine		Refer to "ENGINE REMOVAL" section.
	Cylinder head		Refer to "CYLINDER HEAD" section.
	Cylinder and piston		Refer to "CYLINDER AND PISTON" section.
	Clutch		Refer to "CLUTCH" section.
	Kick starter		Refer to "KICK STARTER" section.
	Primary drive gear/oil pump		Refer to "OIL PUMP" section.
	Balancer gear		Refer to "BALANCER GEAR" section.
	Shift shaft and segment		Refer to "SHIFT SHAFT AND SEGMENT" section.
	CDI magneto/starter clutch		Refer to "CDI MAGNETO AND STARTER CLUTCH" section.
1	Timing chain guide (intake)	1	




Order	Job name/Part name	Q'ty	Remarks
2	Timing chain	1	
3	Crankcase	1	Refer to "CRANKCASE SEPARATION/INSTALLATION" section.
4	Dowel pins	2	Reverse the removal procedure for installation.



CRANKSHAFT AND BALANCER WEIGHT



Order	Job name/Part name	Q'ty	Remarks
	Crankshaft and balancer weight removal		Remove the parts in order.
1	Balancer weight	1	Refer to "BALANCER WEIGHT INSTALLATION" section.
2	Crankshaft assembly	1	
3	Dowel pin	1	Refer to "PLUNGER SEAL REMOVAL/INSTALLATION" section.
4	Plunger seal	1	
5	Compression spring	1	
6	Bearing (balancer weight)	1	
7	Bearing (crankshaft right)	1	
			Reverse the removal procedure for installation.




SR401132

CRANKCASE SEPARATION

1. Remove:
 - Crankcase screws

NOTE: _____

- The numbers embossed on the crankcase indicate the tightening sequence. Loosen the screws in decreasing numerical order (see numbers on the illustration).
- Loosen each screw 1/4 turn at a time and remove them after all are loose.




2. Remove:
 - Right crankcase half

NOTE: _____

Set the left crankcase half under then put in the flat head screw driver to the separating slit (a).

CAUTION: _____

- Do not use the flat head screw driver except place as shown.
- The left crankcase half should be under.
- Separate the crankcase after first checking that the shift cam segments and the drive axle circlip can be removed.
- Do not damage the crankcase mating surfaces.




SR*****

PLUNGER SEAL REMOVAL

1. Remove:
 - Dowel pin ①
 - Plunger seal ②
 - Compression spring ③

NOTE: _____

Remove the plunger seal and compression spring, push the plunger seal lightly and remove the dowel pin.




T*****

CRANKSHAFT INSPECTION

1. Measure:
 - Crankshaft runout
 - Out of specification → Replace crankshaft and/or bearing.


NOTE: _____


Measure the crankshaft runout with the crankshaft assembly turning slowly.




	Runout limit: 0.03 mm
---	--


2. Measure:
 - Big end side clearance
 - Out of specification → Replace big end bearing, crank pin and/or connecting rod.

	Big end side clearance: 0.35 ~ 0.65 mm
	Limit 0.1 mm




3. Measure:
 - Crank width
 - Out of specification → Replace crankshaft.


	Crank width: 55.95 ~ 56.00 mm
---	--



4. Inspect:
 - Timing chain sprocket ①
 - Wear/Damage → Replace crankshaft.
 - Bearing ②
 - Wear/Crack/Damage → Replace crankshaft.




5. Inspect:
 - Crankshaft journal
 - Clogged → Blow out the journal with compressed air.



SR*****

PLUNGER SEAL INSTALLATION

1. Install:
 - Compression spring ①
 - Plunger seal ②
 - Dowel pin ③
2. Check the plunger seal smooth operation pushing the plunger seal by your finger.



T****

BALANCER WEIGHT INSTALLATION

1. Install:
 - Crankshaft assembly ①
 - Balancer weight assembly ②

CAUTION:

Do not use the hammer forcefully during installation of the crankshaft. Damage the crankcase oil seal lip and gear teeth..

SR404073

CRANKCASE INSTALLATION



1. Clean all the gasket mating surface and crankcase mating surface thoroughly.
2. Apply:
 - Sealant
(onto the crankcase mating surfaces)



Yamaha bond No. 1215 :
90890-85505

NOTE:

DO NOT ALLOW any sealant to come in contact with the oil gallery (a).



3. Tighten:
 - Crankcase right half


7 Nm (0.7 m•kg)

NOTE:


Tighten the screws in decreasing numerical order (see numbers on the illustration).




TRANSMISSION, SHIFT CAM AND SHIFT FORK



Order	Job name/Part name	Q'ty	Remarks
	Transmission, shift cam and shift fork removal Crankcase separating		Remove the parts in order. Refer to "CRANKCASE AND CRANK-SHAFT" section.
1	Shift fork guide bar 2 (short length)	1	Refer to "TRANSMISSION, SHIFT CAM AND SHIFT FORK INSTALLATION" section.
2	Shift fork guide bar 1 (long length)	1	
3	Shift cam	1	
4	Shift fork 1 "C" (center)	1	
5	Shift fork 2 "R" (right)	1	
6	Shift fork 3 "L" (left)	1	
7	Main axle assembly	1	
8	Plate washer	1	
9	Drive axle assembly	1	
10	Plate washer	1	
			Reverse the removal procedure for installation.




Order	Job name/Part name	Q'ty	Remarks
	Drive axle and main axle disassembly		Disassemble the parts in order.
①	Second wheel gear	1	
②	First wheel gear	1	
③	Forth wheel gear	1	
④	Circlip/washer	1/1	
⑤	Third wheel gear	1	
⑥	Fifth wheel gear	1	
⑦	Drive axle	1	
⑧	Second pinion gear	1	
⑨	Fifth pinion gear	1	
⑩	Third pinion gear	1	
⑪	Circlip/washer	1/1	
⑫	Forth pinion gear gear	1	
⑬	Main axle	1	
			Reverse the disassembly procedure for assembly.




SR*****

TRANSMISSION, SHIFT CAM AND SHIFT FORK REMOVAL

1. Install:
 - O-Ring ①
To the drive sprocket groove.




2. Remove:
 - Drive axle assembly ①
 - Main axle assembly ②
 Remove them at same the time.




AG402190

SHIFT FORK AND SHIFT CAM INSPECTION

1. Inspect:
 - Shift fork cam follower ①
 - Shift fork pawl ②
 Scoring/bends/wear/damage → Replace.



2. Inspect:
 - Shift cam grooves
Wear/damage/scratches → Replace.
 - Shift cam segment
Damage/wear → Replace.



3. Inspect:
 - Shift fork 1 "C"(center) ①
 - Shift fork 2 "R"(right) ②
 - Shift fork 3 "L"(left) ③
 - Guide bar ④
 - Shift cam ⑤
 - Dowel pin ⑥
 Roll the guide bar on a flat surface.
Bends → Replace.

▲WARNING





Do not attempt to straighten a bent guide bar.



4. Check:
 - Shift fork movement
(on the guide bar)
 - Unsmooth operation → Replace the shift fork and the guide bar.

NOTE: _____

When damaged the shift fork and mission gear, replace the facing each gear as set.



SR*****

TRANSMISSION, SHIFT CAM AND SHIFT FORK INSTALLATION

1. Measure:
 - Main axle assembled length (a)

	Assembled length (main axle): 90.9 ~ 91.1 mm
--	---

2. Install:
 - O-ring (1)
 - To the drive sprocket folder groove.

3. Install:
 - Shift fork 3 "L"(left) (1)
(face the "L" side for the clutch side.)
 - Shift fork 2 "R"(right)(2)
(face the "R" side for the clutch side.)
 - Shift fork 1 "C"(center)(3)
(face the "C" side for the magneto side.)
 - Shift fork guide bar 1 (4) (long)
 - Shift fork guide bar 2 (5) (short)

NOTE: _____

Install the shift forks with the embossed mark to the right and in sequence (R, C, L) beginning from the right.

4. Check:
 - Shift cam operation
 - Unsmooth operation → Repair.

NOTE: _____

Check the transmission and shift forks for smooth operation by turning the shift cam with your hand.

~

~

2


3

4




EB600006


CARBURETION
CARBURETOR



Order	Job name/Part name	Q'ty	Remarks
	Carburetor removal		Remove the parts in order.
	Side cover (left)		Refer to "SIDE COVER, SEAT AND FUEL TANK" section in CHAPTER 3. NOTE: _____ Remove the cover from the pin of the frame and slide back the air filter case.
	Seat		
	Fuel tank		
	Cover (air filter joint)		
	Air filter case		
1	Throttle cable	1	
2	Carburetor joint clamp screw	1	NOTE: _____
3	Air filter joint clamp screw	1	Loosen.
4	Starter cable	1	
5	Carburetor assembly	1	Reverse the removal procedure for installation.



Order	Job name/Part name	Q'ty	Remarks
	Carburetor disassembly		Disassemble the parts in order.
①	Throttle cable	1	
②	Pilot screw	1	
③	Throttle valve assembly	1	
④	Throttle valve spring	1	
⑤	Piston valve	1	
⑥	Pilot air jet	1	
⑦	Drain screw	1	Refer to "CARBURETOR ASSEMBLY" section.
⑧	Float chamber	1	
⑨	Gasket (float chamber)	1	
⑩	Float pin/float	1	



Order	Job name/Part name	Q'ty	Remarks
①	Needle valve assembly	1/1	Refer to "CARBURETOR ASSEMBLY" section.
②	Main jet	1	
③	Pilot jet	1	
④	Main nozzle	1	
⑤	Starter plunger assembly	1	
			Reverse the disassembly procedure for assembly.




AG*****


CARBURETOR ASSEMBLY

CAUTION


- Do not use a wire for cleaning.
- Before assembling, wash all parts in clean petroleum based solvent.
- Always use a new gasket.




1. Install:
 - Main nozzle
 - Pilot jet ①
 - Plug ②
 - Main jet ③




2. Install:
 - Valve seat ①
 - Screw ②



3. Install:
 - Needle valve ①
 - Float ②
 - Float pin ③




4. Install:
 - Main jet washer ①
 - Gasket (float chamber) **New**
 - Float chamber




5. Install:
- Pilot air jet ①
 - Pilot screw ②



Pilot screw (turn out):
2 turns out



6. Install:
- Jet needle ①
 - Piston valve ②
 - Throttle valve spring
 - Starter plunger assembly



YP600060

FUEL LEVEL ADJUSTMENT


1. Measure:
- Fuel level (a)
- Out of specification → Adjust.



Fuel level:
2.5 ~ 3.5 mm below the float chamber line

Measurement and adjustment steps:

- Place the motorcycle on a level surface.
- Put a garage jack under the engine to ensure that the carburetor is positioned vertically.
- Connect the fuel level gauge ① to the drain pipe ②.




Fuel level gauge:
90890-01312

- Loosen the drain screw ③.
- Hold the gauge vertically next to the float chamber line.
- Measure the fuel level (a) with the gauge.
- If the fuel level is incorrect, adjust the fuel level.
- Remove the carburetor.
- Inspect the valve seat and needle valve.
- If either is worn, replace them both.
- If both are fine, adjust float level by bending the float tang ④ slightly.
- Install the carburetor.
- Recheck the fuel level.


EB700000

CHASSIS
FRONT WHEEL AND FRONT BRAKE




Order	Job name/Part name	Q'ty	Remarks
	Front wheel and front brake removal		Remove the parts in order. WARNING Securely support the motorcycle so there is no danger of it falling over.
1	Cable holder (brake cable)	1	
2	Cable holder (meter cable)	1	
3	Front brake cable/spring	1/1	
4	Speedometer cable	1	
5	Cotter pin	1	Refer to "FRONT WHEEL INSTALLATION" section.
6	Wheel axle	1	
7	Front wheel assembly	1	
8	Collar	1	
9	Brake shoe plate assembly	1	Refer to "FRONT WHEEL ASSEMBLY" section. Reverse the removal procedure for installation.

6




6

Order	Job name/Part name	Q'ty	Remarks
	Front wheel disassembly		
①	Oil seal	1	Disassemble the parts in order. Refer to "FRONT WHEEL ASSEMBLY" section.
②	Bearing	1	Refer to "FRONT WHEEL DISASSEM- BLY/ASSEMBLY" section.
③	Spacer	1	
④	Spacer flange	1	
⑤	Bearing	1	Reverse the disassembly procedure for reassembly.



Order	Job name/Part name	Q'ty	Remarks
	Front brake shoe plate disassembly		
①	Brake shoe kit	1	Disassemble the parts in order. Refer to "BRAKE SHOE PLATE ASSEMBLY" section.
②	Oil seal	1	
③	Circlip	1	
④	Washer	1	
⑤	Meter clutch	1	
⑥	Drive gear	1	
⑦	Washer	1	
⑧	Camshaft lever	1	Refer to "BRAKE SHOE PLATE ASSEMBLY" section.
⑨	Indicator plate	1	
⑩	Camshaft	1	
⑪	Meter gear Assembly	1	Refer to "BRAKE SHOE PLATE DISASSEMBLY/ASSEMBLY" section. Reverse the disassembly procedure for assembly.
⑫	O-ring	1	




AG*****

FRONT WHEEL DISASSEMBLY

1. Remove:

- Bearings ①
- Spacer ②
- Collar ③

Remove the bearings using a general bearing puller ④.



AG*****

BRAKE SHOE PLATE DISASSEMBLY


1. Remove:

- Bush ①
- Meter gear ②

Remove the bush using a meter gear bush tool ③.



Meter gear bush tool:
90890-01052



T700021

FRONT WHEEL INSPECTION

1. Inspect:

- Front wheel axle
(by rolling it on a flat surface)
Bends → Replace.

⚠ WARNING

Do not attempt to straighten a bent axle.



Wheel axle bending limit:
0.25 mm

2. Inspect:


- Front tire
Wear/damage → Replace.
Refer to "TIRE INSPECTION" in CHAPTER 3.
- Front wheel
Refer to "WHEEL INSPECTION" in CHAPTER 3.


3. Check:

- Spokes
Bends/damage → Replace.
Loose spokes → Retighten.
Turn the wheel and tap the spokes with a screwdriver.

NOTE:

A tight spoke will emit a clear, ringing tone; a loose spoke will sound flat.






340 004


4. Tighten:
- Loose spokes
 - Nipple


NOTE: _____
 Check the front wheel runout after tightening the spokes.



340-012


5. Measure:
- Front wheel runout
- Over the specified limits → Replace.

	Front wheel runout limits:
	Radial ①: 2.0 mm
	Lateral ②: 2.0 mm




340 002

6. Inspect:
- Front wheel bearings
 Bearings allow free play in the wheel hub or the wheel does not turn smoothly → Replace.
 - Oil seals
 Wear/damage → Replace.
7. Inspect:
- Collar
 Grooved wear → Replace the collar and the oil seal as a set.





SPEEDOMETER GEAR INSPECTION

1. Inspect:
- Meter clutch
 Wear/damage → Replace.



2. Inspect:
- Meter drive gear ①
 - Meter gear ②



T*****

FRONT BRAKE INSPECTION

1. Inspect:

- Brake lining surface
Glazed areas → Replace.
Use coarse sand paper.

NOTE:

After polishing, wipe the polished particles with a cloth

2. Measure:

- Brake lining thickness (a)
Out of specification → Replace.
Measuring points.



Brake lining thickness:

Standard:


4 mm

Limit:

2 mm

NOTE:

Replace the brake shoes as a set if either is worn to the limit.



3. Measure:

- Brake drum inside diameter (a)
Out of specification → Replace the wheel.



Brake drum inside diameter:

Standard:


130 mm

Limit:

131 mm

4. Inspect:

- Brake drum inner surface
Oil/scratches → Repair.
- Oil
Use a rag soaked in lacquer thinner or solvent.
- Scratches
Use an emery cloth.
(lightly and evenly polishing)




5. Inspect:
- Cam shaft face
 - Wear → Replace.

⚠WARNING

When inspecting the brake lining, do not spill oil or grease on the brake lining.

AG*****


BRAKE SHOE PLATE ASSEMBLY




1. Install:
- Camshaft ①
 - Indicator plate ②

Installation steps:

- Align the projection ③ on the indicator plate with the camshaft notch ④ and install.
- Check the proper position of the brake shoe.




2. Install:
- Cam lever ①

 **9 Nm (0.9 m·kg)**

NOTE:

- Align the punch mark ⑤ on the cam shaft with the mark made on the cam lever ⑥.
- Apply lithium soap base grease onto the brake cam shaft and pin.




3. Install:
- Brake shoes ①
 - Tension springs ② **New**

NOTE:


- When installing the springs and brake shoes, take care not to damage the springs.
- Replace the tension spring as a set when replace the brake shoes.


⚠WARNING

After installing the brake cam shaft, remove the excess grease.



4. Install:
- Meter gear ①
 - Bush ②
 - Install the bush using a meter gear bush tool ③.

 **Meter gear bush tool:**
90890-01052



AG*****

FRONT WHEEL ASSEMBLY


1. Install:
 - Bearing ①
 - Spacer
 - Bearing
 - Oil seal

NOTE: _____

- Apply the lithium soap base grease on the bearing and oil seal lip when installing.
- Use a socket that matches the outside diameter of the race of the bearing.
- Always use a new oil seal.
- Install the oil seal with its manufacturer's marks or numbers facing outward.

CAUTION: _____

Do not strike the inner race of balls of the bearing. Contact should be made only with the outer race.



2. Install:
 - Brake shoe plate assembly ①

NOTE: _____

Make sure that the wheel hub and the speedometer gear unit are installed with the two projections (a) meshed into the two slots (b).


3. Install:
 - Hub dust cover
 - Collar


T700030

FRONT WHEEL INSTALLATION

Reverse the "REMOVAL" procedure. Note the following points.


1. Lubricate:
 - Front wheel axle
 - Bearings
 - Oil seal (lips)
 - Drive/driven gear (speedometer)

	Recommended lubricant: Lithium soap base grease
---	---




2. Install:
 - Front wheel

NOTE: _____
 Make sure that the slot (a) in the shoe plate fits over the stopper (b) on the front fork outer tube.

3. Tighten:  **39 Nm (3.9 m•kg)**
 - Front wheel axle
 - Axle nut (front wheel)

NOTE: _____
 Do not loosen the axle nut after torque tightening. If axle nut groove is not aligned with the wheel axle cotter pin hole, align groove to hole by tightening up on the axle nut.


CAUTION: _____
 Before tightening the wheel axle, stroke the front fork several times to check for proper fork operation.



4. Install:
 - Cotter pin ① **New**

NOTE: _____
 Bend the ends of the cotter pin.


WARNING _____
 Always use a new cotter pin.



5. Install:
 - Brake cable
 - Meter cable ①
 - Clip ②

WARNING _____
 Make sure that the brake cable and meter cable is routed properly.


6. Check:
 - Front brake smooth operation
 Unsmooth operation → Disassembly or recheck.
 - Brake lever free play
 Refer to "FRONT BRAKE ADJUSTMENT" section in CHAPTER 3.



YP700040

WHEEL STATIC BALANCE ADJUSTMENT**NOTE:** _____


- After replacing the tire and/or rim, the wheel static balance should be adjusted.
- Adjust the front wheel static balance with the brake disc installed.



1. Remove:
 - Balancing weight ①
2. Set:
 - Wheel
(on a suitable stand)
3. Find:
 - Heavy spot

Procedure:

- a. Spin the wheel and wait for it to rest.
- b. Put an "X₁" mark on the wheel's bottom spot.
- c. Turn the wheel so that the "X₁" mark is 90° up.
- d. Release the wheel and wait for it to rest. Put an "X₂" mark on the wheel's bottom spot.
- e. Repeat the above b., c., and d. several times until all marks come to the same spot.
- f. This spot is the wheel's heavy spot "X".





4. Adjust:
 - Wheel static balance

Adjusting steps:


- Install a balancing weight ① on the rim exactly opposite to the heavy spot "X".

NOTE: _____

Start with the smallest weight.



- Turn the wheel so that the heavy spot is 90° up.
- Check that the heavy spot is at rest there. If not, try another weight until the wheel is balanced.



5. Check:


- Wheel static balance

Checking steps:


- Turn the wheel so that it comes to each point as shown.
- Check that the wheel is at rest at each point. If not, readjust the front wheel static balance.




REAR WHEEL, REAR BRAKE AND DRIVE CHAIN
REAR WHEEL AND REAR BRAKE




Order	Job name/Part name	Q'ty	Remarks
	Rear wheel and rear brake removal		Remove the parts in order.
1	Adjuster (rear brake)	1	
2	Brake rod	1	
3	Pin	1	
4	Compression spring	1	
5	Cotter pin	1	
6	Tension bar	1	
7	Cotter pin	1	
8	Axle nut	1	Refer to "REAR WHEEL INSTALLATION" section.
9	Wheel axle	1	
10	Chain puller	1	
11	Collar	1	



Order	Job name/Part name	Q'ty	Remarks
12	Rear wheel assembly	1	Refer to "REAR WHEEL INSTALLATION" section. Reverse the removal procedure for installation.
13	Brake shoe plate assembly	1	




Order	Job name/Part name	Q'ty	Remarks
	Rear wheel disassembly		Disassemble the parts in order.
①	Bearing	1	Refer to "REAR WHEEL DISASSEMBLY/ ASSEMBLY" section.
②	Collar	1	
③	Spacer	1	
④	Oil seal	1	
⑤	Damper	1	
			Reverse the disassembly procedure for reassembly.




Order	Job name/Part name	Q'ty	Remarks
	Rear brake shoe plate disassembly		Disassemble the parts in order.
①	Brake shoe kit	1	Refer to "BRAKE SHOE PLATE ASSEMBLY" section.
②	Tension springs	2	
③	Cam lever	1	
④	Indicator plate	1	
⑤	Camshaft	1	
			Reverse the disassembly procedure for reassembly.




DRIVE CHAIN, DRIVE SPROCKET AND DRIVEN SPROCKET




Order	Job name/Part name	Q'ty	Remarks
	Drive chain, drive sprocket and driven sprocket removal		Remove the parts in order.
1	Rear wheel Band (boots)	2	NOTE: _____ Loosen the screw.
2	Chain case guard	1	
3	Chain case (upper and lower)	2	Refer to "DRIVE SPROCKET AND DRIVE CHAIN" section.
4	Foot rest (left)	1	
5	Shift pedal	1	
6	Fitting plate/sprocket cover	1/1	
7	Sprocket holder	1	
8	Clip/chain joint/plate	1/1/1	Refer to "DRIVE SPROCKET AND DRIVE CHAIN INSTALLATION" section.
9	Drive chain	1	



Order	Job name/Part name	Q'ty	Remarks
10	Driven sprocket axle nut	1	NOTE: _____ Loosen the axle nut and slacken the drive chain.
11	Chain puller	1	Refer to "DRIVEN SPROCKET INSTALLATION" section.
12	Driven sprocket axle assembly	1	Reverse the removal procedure for installation.



Order	Job name/Part name	Q'ty	Remarks
	Clutch hub disassembly		Disassemble the parts in order.
①	Driven sprocket	1	Refer to "DRIVEN SPROCKET ASSEMBLY" section.
②	Collar	1	
③	Lock washers	3	
④	Oil seal	1	
⑤	Bearing	1	
⑥	Cover	1	
⑦	Clutch hub	1	Reverse the disassembly procedure for assembly.



T*****


REAR WHEEL DISASSEMBLY

1. Remove:
 - Bearings ①
 - Spacer ②
 - Collar ③
 Refer to "FRONT WHEEL".

T701020

REAR WHEEL INSPECTION

1. Inspect:
 - Rear wheel axle
 - Rear wheel
 - Rear wheel bearings
 - Oil seals
 Refer to "FRONT WHEEL".
2. Measure:
 - Rear wheel runout
 Refer to "FRONT WHEEL".




3. Inspect:
 - Clutch hub damper
 Wear/damage → Replace.

SR701021

REAR BRAKE INSPECTION

1. Inspect:
 - Brake lining surface
2. Measure:
 - Brake lining thickness
3. Inspect:
 - Brake drum inner surface
 - Oil
 - Scratches
 Refer to "FRONT WHEEL".
4. Measure:
 - Brake drum inside diameter ①
 Out of specification → Replace.



Brake drum inside diameter:

Standard:




130 mm

Limit:

131 mm



5. Inspect:
 - Cam shaft face
 Refer to "FRONT WHEEL".



T701020

DRIVE CHAIN INSPECTION

1. Inspect:
 - Drive chain stiffness
 Stiffness → Clean and lubricate or replace.

2. Inspect:
 - Drive chain ①
 - Driven sprocket ②
 More than 1/2 tooth a wear → Replace the drive chain.
 Use new driven sprocket.


3. Measure:
 - 10 link length ③ (drive chain)
 Out of specification → Replace the drive chain.



10 link length limit:
122 mm


NOTE:

- Tighten the drive chain with a finger before measuring.
- 10 link length is the distance between the inside edge of roller ① and ⑪ as shown.
- 10 link length measurement should be done at two or three different places.



4. Clean:
 - Drive chain
 Put it in kerosene, and brush off as much dirt as possible. Then remove the drive chain from the kerosene and dry it.

	Drive chain lubricant: Engine oil
--	--




T*****
CLUTCH HUB INSPECTION

1. Inspect:
 - Clutch hub
 Wear/damage/cracks → Replace.


AG*****
BRAKE SHOE PLATE ASSEMBLY

1. Install:
 - Camshaft
 - Indicator plate
2. Install:
 - Cam lever 9 Nm (0.9 m·kg)
3. Install:
 - Brake shoes
 - Tension springs **New**
 Refer to "FRONT WHEEL".



AG*****
REAR WHEEL ASSEMBLY

1. Install:
 - Bearing ①
 - Spacer ②
 - Collar ③
 - Bearing ④
 Refer to "FRONT WHEEL".
2. Install:
 - Clutch hub dumper



T*****


DRIVEN SPROCKET ASSEMBLY

1. Install:

- Driven sprocket ①
- Lock washer ② **New**
- Nut ③

30 Nm (3.0 m·kg)
NOTE:

Tighten the nuts in a crisscross pattern.



2. Bend:

- Lock washer tab ①
(along a flat side of the end)

AG*****



DRIVEN SPROCKET AND DRIVE CHAIN INSTALLATION

1. Install:

- Driven sprocket axle ①
- Collar ②

NOTE:

Align the tab on the swingarm with the slit of collar ③.



2. Install:


- Drive chain ①
- Chain joint ②
- Plate ③


3. Install:

- Clip ① **New**

CAUTION:

Be sure to install the chain joint clip to the direction as shown.





4. Install:
 - Chain case (upper) ①
 - Chain case (lower) ②

NOTE: _____
 Make sure that the chain cases insert to the boots.

4. Tighten:
 - Band
 - Driven sprocket axle

80 Nm (8.0 m•kg)


T701032

REAR WHEEL INSTALLATION

Reverse the "REMOVAL" procedure.
 Note the following points.

1. Install:
 - Brake shoe plate assembly
 - Rear wheel assembly

NOTE: _____
 Make sure that the slot in the rear wheel hub damper fits over the tab on the clutch hub assembly.



2. Adjust:
 - Drive chain slack
 Refer to "DRIVE CHAIN ADJUSTMENT" section in CHAPTER 3.
3. Tighten:
 - Rear wheel axle **80 Nm (8.0 m•kg)**
 - Axle nut (rear wheel)


NOTE: _____
 Do not loosen the axle nut after torque tightening. If axle nut groove is not aligned with the wheel axle cotter pin hole, align groove to hole by tightening up on the axle nut.

4. Install:
 - Cotter pin ① **New**

NOTE: _____
 Bend the ends of the cotter pin.

WARNING


Always use a new cotter pin.




5. Check:
 - Brake pedal free play
 Refer to "REAR BRAKE ADJUSTMENT" section in CHAPTER 3.



FRONT FORK



Order	Job name/Part name	Q'ty	Remarks
	Front fork removal		Remove the parts in order.
	Front wheel		Refer to "FRONT WHEEL AND FRONT BRAKE" section.
	Brake cable and meter cable		
	Handlebar		Refer to "HANDLEBAR" section.
	Headlight unit		
1	Front fender	1	
2	Breather hose	1	
3	Band/fork boots	1/1	
4	Bolt (handle crown)	1	Refer to "FRONT FORK REMOVAL/ INSTALLATION" section.
5	Cap	1	
6	Cap bolt/O-ring	1/1	NOTE: _____
7	Bolts (under bracket)	1	Loosen the under bracket bolt.
8	Front fork assembly	1	Reverse the removal procedure for installation.



Order	Job name/Part name	Q'ty	Remarks
	Front fork disassembly		Disassemble the parts in order.
①	Band/fork boots	1/1	Refer to "FRONT FORK ASSEMBLY" section.
②	Cap bolt/O-ring	1/1	
③	Collar/spring seat	1/1	NOTE:
④	Fork spring	1	Drain the fork oil.
⑤	Dust seal	1	Refer to "FRONT FORK DISASSEMBLY/ASSEMBLY" section.
⑥	Retaining clip	1	
⑦	Bolt/washer	1	Refer to "FRONT FORK ASSEMBLY" section.
⑧	Inner tube assembly	1	
⑨	Damper rod	1	Refer to "FRONT FORK ASSEMBLY" section.
⑩	Rebound spring	1	
⑪	Oil lock piece	1	Reverse the disassembly procedure for assembly.
⑫	Oil seal	1	
⑬	Outer tube	1	



AG703010

FRONT FORK REMOVAL


WARNING

Securely support the motorcycle so there is no danger of it falling over.

1. Stand the motorcycle on a level surface.
2. Elevate the front wheel by placing a suitable stand under the engine.
3. Loosen:
 - Pinch bolt (handle crown) ①
 - Cap bolts ②

NOTE:

Use 19 mm width hexagonal wrench for loosening and tightening the cap bolt.

**WARNING**

Support the front fork before loosening the pinch bolts.



AG703020

FRONT FORK DISASSEMBLY

1. Remove:
 - Dust seal ①
 - Retaining clip ② (using a slotted-head screwdriver)

CAUTION:

Take care not to scratch the inner tube.



2. Remove:
 - Bolt (damper rod) ①
 Loosen the bolt (damper rod) ① while holding the damper rod with T-handle ② and holder ③.



Damper rod holder (19 mm):

90890-04084

T-handle


90890-01326

3. Remove:
 - Oil seal ①

CAUTION:

Never reuse the oil seal.

② Rag






YP703030

FRONT FORK INSPECTION

1. Inspect:
 - Inner tube bending




	Inner tube bending limit: 0.2 mm
--	--

Scratches/bends/damage → Replace.

WARNING

Do not attempt to straighten a bent inner tube as this may dangerously weaken the tube.




2. Measure:
 - Fork spring (a)

	Front fork spring free length: 403.5 mm <Wear limit> 399 mm
--	---

Over the specified limit → Replace.

3. Inspect:
 - Damper rod ①
Bends/damage → Replace.
Contamination → Blow out all oil passages with compressed air.
 - Piston ring ②
Wear/cracks/damage → Replace.



CAUTION:

- The front fork has a built-in piston rod and a very sophisticated internal construction which are particularly sensitive to foreign material.
- When disassembling and assembling the front fork do not allow any foreign material to enter the oil.





AG*****

FRONT FORK ASSEMBLY

Reverse the "DISASSEMBLY" procedure.
Note the following points.

NOTE:

- When assembling the front fork be sure to replace the following parts.
 - *Oil seal
 - *Dust seal
- Before assembling the fork, make sure that all of the components are clean.



1. Install:

- Damper rod ①
- Rebound spring ②
- Oil lock piece ③
- Inner tube ④

NOTE:

Install the damper rod into the inner tube before install to the outer tube.

2. Install:


- Inner tube ①
- Into outer tube ②.

3. Install:

- Washer ① **New**
- Bolt (damper rod) ②


4. Tighten:






- Bolt (damper rod) ②

 **30 Nm (3.0 m•kg)**

NOTE:

Tighten the damper rod bolt ② while holding the damper rod with a T-handle ③ and a damper rod holder ④.

	Damper rod holder (19 mm):
	90890-04084
	T-handle
	90890-01326



5. Install:

- Oil seal ① **New**
- Retaining clip ②
- Dust seal ③ **New**


Use the fork seal driver weight ④ and the attachment ⑤.

NOTE: _____

- Before installing the oil seal ①, apply lithium soap base grease onto the oil seal lips.
- Adjust the retaining clip so that it fits into the outer tube groove.

CAUTION: _____

Make sure that the oil seal numbered side faces upward.


	Fork seal driver weight:
	90890-01367
	Attachment:
	90890-01369

6. Inspect:



- Inner tube operation
Unsmooth operation → Disassembly and recheck.

7. Fill:

- Fork oil ①

	Oil quantity:
	0.294 L
	Recommended oil:
	Fork oil 15WT or equivalent

8. After filling up, slowly pump the fork up and down to distribute the fork oil.



9. Measure:

- Oil level (a)

Out of specification → Adjust.



Oil level:

117 mm

(from the top of the inner tube fully compressed and without the fork spring)

NOTE:

Hold the fork in an upright position.

10. Install:

- Front fork spring (1)

NOTE:

- Install the fork spring with its smaller pitch upward.
- Before installing the cap bolt, apply grease to the O-ring.
- Temporarily tighten the cap bolt.

11. Install:

- Spring seat
- Spacer
- O-ring **New**
- Cap bolt
- Fork boots

EB703050

FRONT FORK INSTALLATION

Reverse the "REMOVAL" procedure.

Note the following points.



1. Install:

- Front fork (1)

Temporary tighten the pinch bolts.

NOTE:

Pull up the inner tube until its end flushes the top of the under bracket, then temporarily tighten the bolt (under bracket lower).



2. Tighten:

- Pinch bolts (under bracket upper/lower)

23 Nm (2.3 m•kg)

- Cap bolts (2)

23 Nm (2.3 m•kg)


- Pinch bolts (handle crown)

34 Nm (3.4 m•kg)


NOTE:

Refer to cable routing and insert the front fork breather hose into the headlight body.






HANDLEBAR



Order	Job name/Part name	Q'ty	Remarks
	Handlebar removal		Remove the parts in order.
1	Bush guard	1	
2	Headlight unit	1	
3	Handlebar switch lead (left and right), front brake switch lead, clutch switch lead and flasher relay	1	NOTE: _____ Disconnect the couplers and connectors.
4	Front carrier assembly	1	
5	Starter cable	1	
6	Housing (throttle grip)	1	
7	Throttle cable	1	Refer to "HANDLEBAR INSTALLATION" section.
8	Throttle grip assembly	1	
9	Handlebar switch (right)	1	
10	Front brake lever assembly	1	
11	Handlebar switch (left)	1	



Order	Job name/Part name	Q'ty	Remarks
12	Clutch switch	1	
13	Clutch cable	1	
14	Grip (left)	1	Refer to "HANDLEBAR REMOVAL" section.
15	Clutch lever assembly	1	
16	Upper holders	2	Refer to "HANDLEBAR INSTALLATION" section. Reverse the removal procedure for installation.
17	Handlebar	1	



YP*****

HANDLEBAR REMOVAL

1. Remove:
 - Grip (Left)

Removal steps:

- Blow with compressed air between the handlebar and adhesive side of the grip to remove.

YP704020

HANDLEBAR INSPECTION

1. Inspect:
 - Handlebar
 - Bush guard
 Bends/Cracks/Damage → Replace.

▲WARNING

Do not attempt to straighten a bent handlebar as this may dangerously weaken the handlebar.

SR*****

HANDLEBAR INSTALLATION

1. Install:
 - Handlebar ①
 - Upper handlebar holder ②

20 Nm (2.0 m•kg)

NOTE:

- Apply a light coat of lithium soap base grease onto the handlebar right end.
- The upper handlebar holders should be installed with the longer side (a) to the forward, then tighten the front bolt as shown.

2. Install:

- Front brake lever assembly ①
- Handlebar switch (right)
- Grip assembly
- Throttle cable
- Housing (throttle grip)

NOTE:

Align the projection (a) on the handlebar switch with the hole (b) in the handlebar.

▲WARNING

Check the throttle grip for smooth operation.




3. Adjust:

- Throttle cable free play
- Brake operation


Refer to "THROTTLE CABLE ADJUSTMENT/BRAKE LEVER ADJUSTMENT" section in CHAPTER 3.




**STEERING
UNDER BRACKET**



Order	Job name/Part name	Q'ty	Remarks
	Under bracket removal		Remove the parts in order.
	Front fork and front fender		Refer to "FRONT FORK" section.
	Handlebar		Refer to "HANDLEBAR" section.
1	Meter cable/Meter lead/flasher lead	1/1/1	NOTE: _____
2	Front carrier assembly	1	Disconnect the couplers and connectors and remove the assembled parts in the front carrier (main switch, meter assembly, flasher relay, terminal assembly, flasher lights .) as a set.
3	Handle crown	1	_____
4	Ring nut	1	Refer to "STEERING REMOVAL/INSTALLATION" section.
5	Ball race cover	1	
6	Under bracket	1	
7	Ball race (upper)	1	



Order	Job name/Part name	Q'ty	Remarks
8	Ball	22	Refer to "STEERING INSTALLATION" section.
9	Ball	19	
10	Ball race (center)	1	
11	Ball race (lower)	1	
12	Steering seal	1	Reverse the removal procedure for installation.



YP704010

STEERING REMOVAL

⚠WARNING


- Securely support the motorcycle so that there is no danger of it falling over.
- Stand the motorcycle on a level surface.

1. Remove:

- Ring nut ①

Use a exhaust and steering nut wrench

②.

	Exhaust and steering nut wrench: 90890-01268
---	---

⚠WARNING

Securely support the steering shaft so that there is no danger of it falling down.

STEERING INSPECTION



1. Wash the bearing and ball races with a solvent.
2. Inspect:
 - Bearings
 - Ball races
 Pitting/Damage→Replace.

Bearing race replacement steps:

- Remove the ball races on the head pipe using long rod ① and the hammer as shown.
- Remove the ball race on the under bracket using the floor chisel ② and the hammer as shown.
- Install the new dust seal and races.

NOTE:


- Always replace bearings and races as a set.
- Replace the dust seal whenever a steering head disassembled.



354 007

CAUTION:

If the bearing race is not fitted squarely, the head pipe could be damaged.



EB704030

STEERING INSTALLATION

Reverse the "REMOVAL" procedure.
Note the following points.

1. Lubricate:
 - Bearings (upper and lower)
 - Ball races



Recommended lubricant:
Lithium-soap base grease


2. Install:

- Ring nut ①


38 Nm (3.8 m·kg)

Refer to "STEERING HEAD INSPECTION" section in CHAPTER 3.


REAR SHOCK ABSORBER AND SWINGARM



Order	Job name/Part name	Q'ty	Remarks
	Rear shock absorber and swingarm removal		Remove the parts in order.
	Seat, fuel tank, and side cover		Refer to "SIDE COVER, SEAT AND FUEL TANK" section in CHAPTER 3.
	Rear wheel		Refer to "REAR WHEEL, REAR BRAKE AND DRIVE CHAIN" section.
	Foot rest assembly (left and right)		
	Brake pedal		
	Chain case guard, chain case		
	Drive chain, driven sprocket		
1	Drive chain guide	1	
2	Mud guard	1	
3	Boots	1	
4	Pin/shaft	1/1	
5	Rear shock absorber	1	




Order	Job name/Part name	Q'ty	Remarks
6	Pivot shaft	1	
7	Swingarm	1	
8	Boots (drive chain)	1	
9	Bushes	3	
10	Collars	2	
			Reverse the removal procedure for installation.




T*****
SWINGARM INSPECTION

- Inspect:
 - Swingarm looseness
Looseness exists → Tighten the pivot shaft nut or replace bushes.
 - Swingarm up and down movement
Unsmooth movement/bending/rough spots → Replace bushes.



AG*****
SWINGARM SIDE CLEARANCE ADJUSTMENT


- Measure:
 - Collar length (swingarm right side) (a)



- Measure:
 - Pivot width (swingarm pivot right side) (b)

NOTE: _____
Install the bush to the both side of the pivot right side, when measure the pivot width


- Calculate:
 - Side clearance (c)
Out of specification → Adjust side clearance using shim.
By using formula given below.



Side clearance:
$$c = a - b = 0.1 \sim 0.4 \text{ mm}$$

Example:

- If the collar length (swingarm right side) (a) is bellow.
a: 54.5 mm
 - If the pivot width (swingarm pivot right side) (b) is bellow.
b: 54.0 mm
 - Side clearance
c = 54.5 - 54.0
= 0.5 mm
- Then, install the one shim.
c = 54.5 - (54.0 + 0.3)
= 0.2 mm





NOTE: _____

- Shim thickness: 0.3 mm
- If the side clearance is not within specification, adjust it by means of shim.
- If only one shim is used, install it on the left side.
- Two shims must be installed both side.

AG705010

REAR SHOCK ABSORBER

HANDLING NOTES

⚠WARNING _____

- This shock absorber contains highly compressed nitrogen gas. Read and make sure you understand the following information before handling the shock absorber. The manufacturer cannot be held responsible for property damage or personal injury that may result from improper handling.
- Do not tamper or attempt to open the cylinder assembly.
- Do not subject the shock absorber to an open flame or any other source of high heat. This may cause the unit to explode due to excessive gas pressure.
- Do not deform or damage the cylinder in any way. Cylinder damage will result in poor damping performance.

EB705020


NOTES ON DISPOSAL

Shock absorber disposal procedure:

- Gas pressure must be released before disposing of the shock absorber. To do so, drill a 2 ~ 3 mm hole through the cylinder wall at a point 15 ~ 20 mm from the end of the gas chamber.

⚠WARNING _____

Wear eye protection to prevent eye damage from released gas and/or metal chips.









EB800000

**ELECTRICAL
ELECTRICAL COMPONENTS**

- | | | |
|---|---------------------------|-----------------|
| ① Flasher relay | ⑦ Starter relay/main fuse | ⑭ Neutral relay |
| ② Auxiliary DC terminal | ⑧ Rear brake switch | |
| ③ Main switch | ⑨ Neutral switch | |
| ④ Battery | ⑩ Horn | |
| ⑤ Fuse holder assembly
(for auxiliary DC terminal) | ⑪ Spark plug cap | |
| ⑥ Rectifier/Regulator | ⑫ Ignition coil | |
| | ⑬ CDI unit | |



7



YP-N

SWITCH INSPECTION

INSPECTION STEPS

Using pocket tester, check switches for continuity between their terminals to determine whether they are correctly connected.

Replace the switch component if any of the combinations does not produce the correct reading.



Pocket tester:

90890-03112

NOTE:

- Turn the switch to the "ON", "OFF" positions several times.
- Adjust the pocket tester to correct "0" position before checking switches.
- Set the pocket tester selector to "x1"Ω.

SWITCH CONNECTION AS SHOWN IN THIS MANUAL


This manual contains connection charts, like the one shown on the left, showing the terminal connections of switches (e.g. the main switch, handlebar switch, brake switch, lighting switch etc.)

The column on the extreme left indicates the different switch positions, the top line indicates the colors of the leads connected to the terminals on the switch.

"○—○" indicates terminals between which there is continuity, i.e. a closed circuit, in the given switch position.

In this chart:

"Br and R" have continuity with the switch in the "ON" position.




SWITCH CONTINUITY INSPECTION


Refer to "SWITCH INSPECTION" and check for continuity between lead terminals.

Poor connection, no continuity → Correct or replace.

*The coupler locations are circled.




- | | | |
|-------------------------|----------------------|--------------------------------|
| ① Turn switch | ⑦ Main switch | ⑬ Fuse (main) |
| ② Lights switch | ⑧ Start switch | ⑭ Fuse (auxiliary DC terminal) |
| ③ Dimmer switch | ⑨ Engine stop switch | |
| ④ Horn switch | ⑩ Front brake switch | |
| ⑤ Clutch switch | ⑪ Rear brake switch | |
| ⑥ Auxiliary DC terminal | ⑫ Neutral switch | |



EB802000

**IGNITION SYSTEM
CIRCUIT DIAGRAM**



- ① CDI magneto
- ⑦ Main switch
- ⑨ CDI unit
- ⑩ Ignition coil
- ⑪ Spark plug
- ⑮ Engine stop switch



SR802010

TROUBLESHOOTING

**IF THE IGNITION SYSTEM FAILS TO OPERATE.
(NO SPARK OR INTERMITTENT SPARK)**

Procedure

Check:


- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Spark plug 2. Ignition spark gap 3. Spark plug cap resistance 4. Ignition coil 5. Pickup coil resistance | <ol style="list-style-type: none"> 6. Source coil resistance 7. Main switch 8. Engine stop switch 9. Wiring connection
(entire ignition system) |
|---|---|

NOTE:


•Remove the following parts before troubleshooting.

- 1) Side cover (left and right)
- 2) Seat
- 3) Fuel tank
- 4) Headlight unit

•Use the special tools specified in the troubleshooting section.

	<p>Ignition checker 90890-06754</p> <p>Pocket tester: 90890-03112</p>
---	---

yp*****






YP*****

2. Ignition spark gap

- Disconnect the spark plug cap from the spark plug.
- Connect the ignition checker ① as shown.
- ② Spark plug cap
- Turn the main switch to "ON".
- Check the ignition spark gap ②.
- Check the spark by pushing the starter switch, and increase the spark gap until a misfire occurs.



Minimum spark gap:
6 mm



MEETS SPECIFICATION

The ignition system is not faulty.



OUT OF SPECIFICATION OR NO SPARK

YP*****

3. Spark plug cap resistance


- Remove the spark plug cap.
- Connect the pocket tester ($\Omega \times 1k$) to the spark plug cap.

NOTE:

- When removing the spark plug cap, do not pull the spark plug cap from high tension cord.
Remove → Turning counterclockwise.
Connect → Turning clockwise.
- Check the high tension cord when connecting the spark plug cap.
- When connecting the spark plug cap, cut the high tension cord about 5 mm.



Spark plug cap resistance:
10k Ω (20°C)



OUT OF SPECIFICATION

Replace the spark plug cap.



MEETS SPECIFICATION





YP*****

4. Ignition coil resistance

- Disconnect the ignition coil connector from the wireharness.
- Connect the pocket tester ($\Omega \times 1$) to the ignition coil.
- Check if the primary coil has the specified resistance.

Primary coil resistance:
0.27 ~ 0.33 Ω (20°C)



- Connect the pocket tester ($\Omega \times 1k$) to the ignition coil.
- Check the secondary has the specified resistance.

Secondary coil resistance:
5.76 ~ 8.52k Ω (20°C)

OUT OF SPECIFICATION

Replace the ignition coil.

BOTH MEET SPECIFICATION





yp*****


5. Pickup coil resistance


- Disconnect the pickup coil coupler from the wireharness.
- Connect the pocket tester ($\Omega \times 100$) to the pickup coil coupler.

Tester (+) lead →
Red Terminal ①

Tester (-) lead →
White Terminal ②

- Check the pickup coil has the specified resistance.

 **Pickup coil resistance:**
656 ~ 984 Ω (20°C)



OUT OF SPECIFICATION

Replace the pickup coil.



MEETS SPECIFICATION

T*****

6. Source coil resistance

- Disconnect the source coil coupler from the wireharness.
- Connect the pocket tester ($\Omega \times 100$) to the charging coil coupler.


Source coil 1:
Tester (+) lead →
Brown Terminal ①

Tester (-) lead →
Green Terminal ②


Source coil 2:
Tester (+) lead →
Yellow Terminal ③

Tester (-) lead →
Green Terminal ②

- Check the source coil has the specified resistance.


 **Source coil 1 resistance:**
700 ~ 900 Ω (20°C)

Source 2 coil 2 resistance:
472 ~ 708 Ω (20°C)




OUT OF SPECIFICATION

Replace the source coil.




MEETS SPECIFICATION




EB80300

**ELECTRIC STARTING SYSTEM
CIRCUIT DIAGRAM**



- ③ Starter relay
- ④ Battery
- ⑤ Fuse (main)
- ⑥ Starter motor
- ⑦ Main switch
- ⑧ Neutral relay
- ⑫ Clutch switch
- ⑭ Start switch
- ⑮ Engine stop switch
- ⑰ Neutral switch



SR*****

STARTING CIRCUIT OPERATION

The starting circuit on this model consists of the starter motor, starter relay, and the neutral relay. If the engine stop switch and the main switch are both closed, the starter motor can operate only if:

The transmission is in neutral (the neutral relay is closed).


or if

The clutch lever is pulled to the handlebar (the clutch switch is closed).

← WHEN THE TRANSMISSION IS IN NEUTRAL

← WHEN THE CLUTCH LEVER IS PULLED IN

- ① Battery
- ② Main fuse
- ③ Main switch
- ④ Engine stop switch
- ⑤ Neutral relay
- ⑥ Clutch switch
- ⑦ Neutral switch
- ⑧ Start switch
- ⑨ Starter relay
- ⑩ Starter motor



YP803020

TROUBLESHOOTING

IF THE STARTER MOTOR FAILS TO OPERATE.

Procedure

Check:

- | | |
|---|--|
| <ol style="list-style-type: none"> 1. Fuse 2. Battery 3. Starter motor 4. Starter relay 5. Neutral relay 6. Main switch | <ol style="list-style-type: none"> 7. Engine stop switch 8. Neutral switch 9. Clutch switch 10. Start switch 11. Wiring connection
(entire starting system) |
|---|--|


NOTE:

- Remove the following parts before troubleshooting.
 - 1) Side cover (left and right)
 - 2) Headlight unit
 - 3) Seat
 - 4) Fuel tank

- Use the special tools specified in the troubleshooting section.

	<p>Pocket tester: 90890-03112</p>
--	--

YP*****





YP*****

3. Starter motor

- Connect the battery positive terminal ① and starter motor cable ② using a jumper lead ③*.
- Check the starter motor operation.

*

WARNING

- A wire used as a jumper lead must have the equivalent capacity as that of the battery lead or more, otherwise it may burn.
- This check is likely to produce sparks, so be sure that no flammable gas or fluid is in the vicinity.

DOES NOT MOVE

Repair or replace the starter motor.

MOVES

YP*****


4. Starter relay

- Disconnect the relay unit coupler from the wireharness.
- Connect the pocket tester ($\Omega \times 1$) and battery (12V) to the relay unit coupler terminals.

Battery (+) lead → Blue/White terminal ①
Battery (-) lead → Red/White terminal ②

- Check the starter relay for continuity.

Tester (+) lead → ③ terminal
Tester (-) lead → ④ terminal




NO CONTINUITY

Replace the starter relay.

CONTINUITY

*



SR*****

5. Neutral relay

- Remove the relay from the frame.
- Connect the pocket tester ($\Omega \times 100$) to the Battery and the relay connector.


Tester (+) lead →
Brown terminal ①

Tester (-) lead →
Blue/White terminal ②

Battery (+) lead →
Brown terminal ①

Battery (-) lead →
Black/Yellow ③ or Sky blue ④ terminal

Check the neutral relay for continuity.



NO CONTINUITY

Replace the neutral relay.



YP*****

6. Main switch

Refer to "SWITCH INSPECTION" section.

NO CONTINUITY

Replace the main switch.



YP*****

7. Engine stop switch

Refer to "SWITCH INSPECTION" section.

NO CONTINUITY

Replace the handlebar switch (right).



YP*****

8. Neutral switch

Refer to "SWITCH INSPECTION" section.

NO CONTINUITY (at NEUTRAL position)

Replace the neutral switch.



YP*****


9. Clutch switch


Refer to "SWITCH INSPECTION" section.

NO CONTINUITY


Replace the clutch switch.







STARTER MOTOR




Order	Job name/Part name	Q'ty	Remarks
	Starter motor removal Drain the engine oil		Remove the parts in order. Refer to "ENGINE OIL REPLACEMENT" section in CHAPTER 3.
1	Starter motor lead	1	Reverse the removal procedure for installation.
2	Starter motor	1	
3	O-ring	1	
	Starter motor disassembly		Disassemble the parts in order.
①	Front bracket	2	Refer to "Assembly" section.
②	Washer set	1	
③	Rear bracket	1	
④	O-ring	1	
⑤	Brush holder/brush	1	
⑥	Armature coil	1	
			Reverse the disassembly procedure for assembly.



YP803034

Inspection and repair


1. Inspect:
 - Commutator
Dirt→Clean it with #600 grit sandpaper.
2. Measure:
 - Commutator diameter (a)



Commutator wear limit:
21 mm

Out of specification→Replace the starter motor

3. Measure:
 - Mica undercut (a)




Mica undercut:
1.5 mm


Out of specification→Scrape the mica to the proper value (a hacksaw blade can be ground to fit).

NOTE:

The mica insulation of the commutator must be undercut to ensure proper operation of commutator.

4. Inspect:
 - Armature coil resistances (installation/continuity)
Defects→Replace the starter motor.
If commutator is dirty, clean it with sandpaper.




	Good condition	Bad condition		
	A	○	○	×
B	×	○	×	○

○: Continuity

×: No continuity

Bad condition→Replace.

5. Measure:
 - Brush length (a)
Out of specification→Replace.




Brush length wear limit:
3.5 mm



ELECTRICAL STARTING SYSTEM


ELEC



6. Measure:
- Brush spring force
Fatigue/out of specification → Replace as a set.



Brush spring force:
560 ~ 840 g




7. Inspect:
- Oil seal
Wear/damage → Replace.

YP*****

Assembly

Reverse the "Disassembly" procedure.
Note the following points.

1. Install:
- Brush holder
 - Brush springs ①
 - Brush ②




2. Install:
- Armature coil ①

NOTE: _____


Hold the brush by the flat head driver, install the armature coil to the brush holder.

CAUTION: _____

Take care the brush.





3. Install:
- O-ring ① **New**
 - Stator assembly ②



4. Install:
- Front bracket ①


NOTE: _____

- Apply molybdenum grease lightly on to the bearings of the starter motor.
- Align the match marks on the yoke with the match marks on the brackets.





5. Install:
- Tang washer ①
 - Plate washer ②
 - Front bracket ③

NOTE: _____
Align the match marks on the stator assembly with the match marks on the front bracket.




6. Tighten:
- Bolt ①

 **5 Nm (0.5 m·kg)**




YP804000

**CHARGING SYSTEM
CIRCUIT DIAGRAM**



- ① CDI magneto
- ② Rectifier/Regulator
- ④ Battery
- ⑤ Fuse (main)



YP804010

TROUBLESHOOTING

IF THE BATTERY IS NOT CHARGED

Procedure

Check:

- 1. Fuse
- 2. Battery
- 3. Charging voltage
- 4. Stator coil resistance
- 5. Wiring system (entire charging system)

NOTE:

- Remove the following parts before troubleshooting.
 - 1) Side cover (left and right)
 - 2) Seat
 - 3) Fuse
- Use the special tools specified in the troubleshooting section.



Engine tachometer
90890-03113
Pocket tester:
90890-03112

yp*****

1. Fuse
Refer to "SWITCH INSPECTION" section.

NO CONTINUITY

Replace the fuse.

CONTINUITY

yp*****


2. Battery
•Check the battery condition.
Refer to "BATTERY INSPECTION" section in CHAPTER 3.

INCORRECT

•Clean battery terminals.
•Recharge or replace the battery.

CORRECT

*



YP*****


3. Charging voltage

- Connect the engine tachometer to the spark plug lead.
- Connect the pocket tester (DC20V) to the battery.


Tester (+) lead →
Battery (+) terminal ①

Tester (-) lead →
Battery (-) terminal ②

- Measure the battery terminal voltage.
- Start the engine and accelerate to about 5,000 r/min.
- Check the terminal voltage.

 **Charging voltage:**
14.1 ~ 14.9V at 5,000 r/min

NOTE: _____
Use a fully charged battery.



MEETS SPECIFICATION

The charging circuit is not faulty.
Replace the battery.

OUT OF SPECIFICATION


YP*****

4. Stator coil resistance


- Remove the CDI magneto coupler from wireharness.
- Connect the pocket tester ($\Omega \times 1$) to the stator coil.

Tester (+) lead → White terminal
Tester (-) lead → White terminal

- Measure the stator coil resistance.



 **Stator coil resistance:**
0.48 ~ 0.72 Ω (20°C)


OUT OF SPECIFICATION



Replace the stator coil.


MEETS SPECIFICATION
*






EB804000

**LIGHTING SYSTEM
CIRCUIT DIAGRAM**



- ④ Battery
- ⑤ Fuse (main)
- ⑦ Main switch
- ⑯ Fuse (auxiliary DC terminal)
- ⑰ Auxiliary DC terminal
- ⑲ Meter light
- ⑳ Tail/Brake light
- ㉘ Dimmer switch
- ㉙ Headlight
- ⑳ Lights switch



YP805070

TROUBLESHOOTING

**IF THE HEADLIGHT, TAILLIGHT AND/OR METER LIGHT FAIL TO COME ON.
IF THE DC VOLTAGE FROM AUXILIARY DC TERMINAL, DOSE NOT PUT PUT.**

Procedure

Check:

- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Fuse 2. Battery 3. Main switch 4. Lights switch | <ol style="list-style-type: none"> 5. Dimmer switch 6. Wiring connection
(entire lighting system) |
|---|---|

NOTE:

•Remove the following parts before troubleshooting.

- 1) Seat
- 2) Fuel tank
- 3) Side cover (left and right)
- 4) Headlight unit

•Use the special tools specified in the troubleshooting section.



Pocket tester:
90890-03112

YP*****

1. Fuse
Refer to "SWITCH INSPECTION" section.

NO CONTINUITY

CONTINUITY

Replace the fuse.

YP*****

2. Battery
•Check the battery condition.
Refer to "BATTERY INSPECTION" section in CHAPTER 3.

INCORRECT

CORRECT

•Clean battery terminals.
•Recharge or replace the battery.

YP*****



3. Main switch
Refer to "SWITCH INSPECTION" section.

NO CONTINUITY

CONTINUITY

Replace the main switch.





*




SR805020

LIGHTING SYSTEM CHECK

1. If the headlight fails to come on.



*



*

- Turn the main switch to on position.
- Turn the lights switch to on position.
- Turn the dimmer switch to low beam or high beam.
- Check for voltage (12V) on the lead at bulb socket connectors.

OUT OF SPECIFICATION

The wiring circuit from the main switch to bulb socket connector is faulty. Repair.

MEETS SPECIFICATION

This circuit is not faulty.

SR805021

2. If the meter light fails to come on.

1. Bulb and bulb socket

Refer to "SWITCH INSPECTION" section.

NO CONTINUITY

Replace the bulb and/or bulb socket.

CONTINUITY

2. Voltage


- Connect the pocket tester (DC20V) to the bulb socket coupler.

Tester (+) lead →

Blue/White terminal ①

Tester (-) lead →

Black terminal ②




- Turn the main switch to on.
- Turn the lights switch to on position.
- Turn the dimmer switch to low beam or high beam.
- Check the voltage (12V) of the leads on the bulb socket connector.

OUT OF SPECIFICATION

The wiring circuit from main switch to bulb socket is faulty. Repair.

MEETS SPECIFICATION

This circuit is not faulty.



YP805022

3. The taillight fails to come on.

1. Bulb and bulb socket
 Refer to "SWITCH INSPECTION" section.

CONTINUITY

2. Voltage
 • Connect the pocket tester (DC20V) to the bulb socket connector.

Tester (+) lead →
Blue terminal ①
 Tester (-) lead →
Black terminal ②


• Turn the main switch to on position.
 • Turn the lights switch to on position.
 • Turn the dimmer switch to low beam or high beam.
 • Check the voltage (12V) on the bulb socket connector.

MEETS SPECIFICATION

This circuit is not faulty.

NO CONTINUITY

Replace the bulb and/or bulb socket.



OUT OF SPECIFICATION

The wiring circuit from main switch to bulb connector is faulty. Repair.

AG*****

AUXILIARY DC OUTPUT SYSTEM CHECK

1. The auxiliary DC terminal fails to put out.

1. Terminal fuse
 Refer to "SWITCH INSPECTION" section.

CONTINUITY

2. Voltage
 • Disconnect the auxiliary DC terminal socket connector.
 • Connect the pocket tester (DC20V) to the auxiliary DC terminal connector from main harness.

Tester (+) lead →
Pink terminal ①
 Tester (-) lead →
Black terminal ②


• Turn the main switch to on position and start the engine.
 • Check the voltage (12V) on the auxiliary DC terminal connector.

MEETS SPECIFICATION

This circuit is not faulty.

NO CONTINUITY

Replace the terminal fuse.




OUT OF SPECIFICATION


The wiring circuit from main switch to terminal socket connector is faulty. Repair.

EB806000

**SIGNAL SYSTEM
CIRCUIT DIAGRAM**



- ④ Battery
- ⑤ Fuse (main)
- ⑦ Main switch
- ⑩ Neutral indicator light
- ⑪ Neutral switch
- ⑫ Rear brake switch
- ⑬ Front brake switch
- ⑭ Tail/Brake light
- ⑮ Flasher relay
- ⑯ Turn switch
- ⑰ Flasher lights
- ⑳ Horn switch
- ㉓ Horn



YP806010

TROUBLESHOOTING

IF THE FLASHER LIGHT, BRAKE LIGHT AND/OR INDICATOR LIGHT FAIL TO COME ON.
IF THE HORN FAILS TO SOUND.

Procedure

Check:


- 1. Fuse
- 2. Battery
- 3. Main switch
- 4. Wiring connection (entire signal system)

NOTE:

- Remove the following parts before troubleshooting.
 - 1) Headlight unit
 - 2) Side cover (left and right)
- Use the special tools in the troubleshooting section.



Pocket tester:
90890-03112





yp*****



4. Wireharness
•Check the connections of the entire signal system.
Refer to "CIRCUIT DIAGRAM" section.

POOR CONNECTION



Correct.



CORRECT

Check condition of each of the signal system's circuits.
Refer to "SIGNAL SYSTEM CHECK" section.



YP806020

SIGNAL SYSTEM CHECK

1. If the horn fails to sound.

1. Horn switch

Refer to "SWITCH INSPECTION" section.

CONTINUITY

2. Voltage

- Connect the pocket tester (DC20V) to the horn lead.

Tester (+) lead → Brown terminal ①
Tester (-) lead → Frame ground

- Turn the main switch to on.
- Check for voltage (12V) on the "Brown" lead at the horn terminal.

MEETS SPECIFICATION

3. Horn

- Connect the pocket tester (DC20V) to the horn at the "Pink" terminal.

Tester (+) lead → Pink ① terminal
Tester (-) lead → Frame ground


- Turn the main switch to on.
- Check for voltage (12V) on the "Pink" lead to frame ground.

MEETS SPECIFICATION

Adjust or replace horn.


NO CONTINUITY

Replace the left handlebar switch (left).



OUT OF SPECIFICATION

The wiring circuit from the main switch to the horn is faulty. Repair.




OUT OF SPECIFICATION

Replace the horn.



YP806022

2. If the brake light fails to come on:





YP806023

3. If the flasher light fails to blink.

1. Bulb and bulb socket
Refer to "SWITCH INSPECTION" section.

NO CONTINUITY

Replace the bulb and/or bulb socket.

CONTINUITY

2. Turn switch
Refer to "SWITCH INSPECTION" section.

NO CONTINUITY

Replace the left handlebar switch (left).


CONTINUITY

3. Voltage

- Connect the pocket tester (DC20V) to the flasher relay coupler.
- **Tester (+) lead → Brown terminal ①**
- **Tester (-) lead → Frame ground**
- Turn the main switch to on.
- Check for voltage (12V) of the "Brown" ① lead at the flasher relay terminal.

OUT OF SPECIFICATION

The wiring circuit from main switch to flasher relay connector is faulty. Repair.




MEETS SPECIFICATION

4. Flasher relay

- Connect the pocket tester (DC20V) to the flasher relay coupler.
- **Tester (+) lead → Brown/White terminal ①**
- **Tester (-) lead → Frame ground**
- Turn the main switch to on.
- Check for voltage (12V) on the "Brown/White" lead at the flasher relay terminal.


OUT OF SPECIFICATION

The flasher relay is faulty. Replace.



MEETS SPECIFICATION

*




5. Voltage

- Connect the pocket tester (DC20V) to the bulb socket connector.

At flasher light (left)
 Tester (+) lead → Chocolate lead ①
 Tester (-) lead → Black terminal ③

At flasher light (right)
 Tester (+) lead → Dark green lead ②
 Tester (-) lead → Black terminal ③

- Turn the main switch to on.
- Turn the turn switch to left or right.
- Check for voltage (12V) on the "Chocolate" lead and "Dark green" at the flasher light terminal.



MEETS SPECIFICATION

This circuit is not faulty.

OUT OF SPECIFICATION

Wiring circuit from the turn switch to bulb socket connector is fault. Repair. Refer to "CIRCUIT DIAGRAM".

SR006027

4. If the neutral indicator lights fails to operate.

1. Bulb and bulb socket
 Refer to "SWITCH INSPECTION" section.

CONTINUITY

NO CONTINUITY

Replace the bulb and/or bulb socket.

2. Neural switch
 Refer to "SWITCH INSPECTION" section.

CONTINUITY

NO CONTINUITY

Replace the left neural switch.

*




3. Voltage

- Connect the pocket tester (DC20V) to the fuel gauge coupler.

Tester (+) lead →
Brown terminal ①

Tester (-) lead →
Sky blue terminal ②



- Turn the main switch to on position.
- Select the gear position in neutral.
- Check for voltage (12V) of the "Sky blue" lead on the neutral switch.

OUT OF SPECIFICATION



MEETS
SPECIFICATION

Check the connection of the entire signal system.
Refer to "CIRCUIT DIAGRAM".

This circuit is not faulty.

EB90000

TROUBLESHOOTING

NOTE:

The following troubleshooting does not cover all the possible causes of trouble. It should be helpful, however, as a guide to troubleshooting. Refer to the relative procedure in this manual for inspection, adjustment and replacement of parts.

SR90000

STARTING FAILURE/HARD STARTING

FUEL SYSTEM

Fuel tank

- Empty
- Clogged fuel tank cap breather hole
- Deteriorated fuel or fuel containing water or foreign material

Fuel cock

- Clogged fuel hose
- Clogged fuel cock

Carburetor

- Deteriorated fuel or fuel containing water or foreign material
- Clogged pilot jet
- Clogged air passage
- Improperly set pilot screw
- Clogged pilot air passage
- Improperly sealed valve seat
- Improperly adjusted fuel level
- Clogged starter jet
- Damaged carburetor joint
- Improperly tightened carburetor joint clamp hose
- Starter plunger malfunction
- Sucked-in air

Air filter

- Clogged air filter element
- Improper air filter setting

COMPRESSION SYSTEM

Cylinder and cylinder head

- Loose spark plug
- Loose cylinder head
- Broken cylinder head gasket
- Broken cylinder gasket
- Worn, damaged or seized cylinder

Piston and piston ring

- Worn piston
- Worn, fatigued or broken piston ring
- Seized piston ring
- Seized or damaged piston

Valve system

- Improperly adjusted valve clearance
- Improperly sealed valve
- Improperly contacted valve and valve seat
- Improper valve timing
- Broken valve spring
- Seized valve

IGNITION SYSTEM**Battery**

- Improperly charged battery
- Faulty battery

Fuse

- Burnt out, improper connection

Spark plug

- Improper plug gap
- Worn electrodes
- Wire between terminals broken
- Improper heat range
- Faulty spark plug cap

Ignition coil

- Broken or shorted primary/secondary coil
- Faulty high tension cord
- Broken ignition coil body

Ignition system

- Faulty CDI unit
- Faulty pick up coil
- Broken magneto woodruff key

Switch

- Faulty main switch
- Faulty "ENGINE STOP" switch
- Faulty front and/or rear brake switch

Wiring

- Loose battery terminal
- Loose coupler connection
- Improperly grounded
- Broken wireharness

SR901000

POOR IDLE SPEED PERFORMANCE**POOR IDLE SPEED PERFORMANCE****Carburetor**

- Improperly returned starter plunger
- Loose or clogged pilot jet
- Damaged carburetor joint
- Improperly tightened carburetor joint clamp hose
- Improperly adjusted idle speed (Pilot screw), (Throttle stop screw)
- Improperly adjusted throttle cable
- Flooded carburetor

Air filter

- Clogged air filter element

Ignition system

- Faulty spark plug
- Faulty high tension cord
- Faulty CDI unit
- Faulty pick up coil
- Faulty ignition coil

Valve system

- Improperly adjusted valve clearance



EB902000

POOR MEDIUM AND HIGH SPEED PERFORMANCE

POOR MEDIUM AND HIGH SPEED PERFORMANCE

Refer to "STARTING FAILURE/HARD STARTING" section. (Fuel system, electrical system, compression system and valve train)

Carburetor

- Improperly adjusted fuel level
- Clogged main nozzle
- Clogged or loose pilot jet

Air filter

- Clogged air filter element

SR*****

POOR SPEED PERFORMANCE

POOR SPEED PERFORMANCE

Ignition system

- Dirty spark plug
- Improper heat range
- Faulty CDI unit
- Faulty pick up coil

Fuel system

- Clogged fuel tank cap breather hole
- Clogged air cleaner element
- Clogged jet
- Improperly adjusted fuel level

Compression system

- Worn cylinder
- Worn or seized piston ring
- Cylinder head gasket broken
- Cylinder gasket broken
- Carbon deposit build-up
- Improperly adjusted valve clearance
- Improperly contacted valve and valve seat
- Faulty valve timing

Clutch

- Refer to "CLUTCH SLIPPING/Dragging" section

Engine oil

- Improper oil level (low or over oil level)
- Improper quality (Low oil viscosity)
- Deterioration
- Clogged oil passage

Brakes

- Dragging brake

EB904000

CLUTCH SLIPPING/DRAGGING**CLUTCH SLIPPING****Clutch**

- Improperly adjusted clutch cable
- Loose clutch spring
- Fatigued clutch spring
- Worn friction plate/clutch plate
- Incorrectly assembled clutch

Engine oil

- Improper oil level
- Improper quality/(low viscosity)
- Deterioration

CLUTCH DRAGGING**Clutch**

- Warped pressure plate
- Unevenly tensioned clutch spring
- Bent push rod
- Broken clutch boss
- Burnt primary driven gear bushing
- Bent clutch plate
- Swollen friction plate
- Match marks not aligned

Engine oil

- Improper oil level
- Improper quality/(high viscosity)
- Deterioration

EB903000

FAULTY GEAR SHIFTING**HARD SHIFTING**

Refer to "CLUTCH DRAGGING".

SHIFT PEDAL DOES NOT MOVE**Shift shaft**

- Improperly adjusted shift rod
- Bent shift shaft

Shift cam, shift fork

- Groove jammed with impurities
- Seized shift fork
- Bent shift fork guide bar

Transmission

- Seized transmission gear
- Jammed impurities
- Incorrectly assembled transmission

JUMP-OUT GEAR**Shift shaft**

- Improperly adjusted shift lever position
- Improperly returned stopper lever

Shift fork

- Worn shift fork

Shift cam

- Improper thrust play
- Worn shift cam groove

Transmission

- Worn gear dog



SR905000

OVER HEATING OR OVER-COOLING

OVER HEATING

Ignition system

- Improper spark plug gap
- Improper spark plug heat range
- Faulty CDI unit

Fuel system

- Improper carburetor setting
- Improper fuel level adjustment
- Clogged air filter element

Compression system

- Heavy carbon deposit build-up
- Improperly adjusted valve timing
- Improperly adjusted valve clearance

Engine oil

- Incorrect engine oil level
- Improper engine oil quality (High viscosity)
- Low engine oil quality

Brakes

- Dragging brake

AG906001

FAULTY BRAKE

POOR BRAKING EFFECT

Front brake

- Improper brake lever adjustment
- Worn brake shoe
- Improper brake shoe contact
- Worn camshaft
- Worn brake drum
- Mud or water into brake drum inside
- Oily or greasy brake lining
- Faulty brake cable
- Broken or fatigued tension spring
- Faulty camshaft, cam lever

Rear brake

- Improper brake pedal adjustment
- Worn brake shoe
- Improper brake shoe contact
- Worn camshaft
- Worn brake drum
- Mud or water into brake drum inside
- Oily or greasy brake lining
- Faulty brake cable
- Broken or fatigued tension spring
- Faulty camshaft, cam lever

SR907000

**FRONT FORK MALFUNCTION
OIL LEAKAGE**

- Bent, damaged or rusty inner tube
- Damaged or cracked outer tube
- Damaged oil seal lip
- Loose hexagon bolt
- Damaged cap bolt O-ring
- Improperly installed oil seal

MALFUNCTION

- Bent inner tube
- Deformed outer tube
- Damaged fork spring
- Bent cylinder complete
- Improper oil viscosity (High viscosity)
- Improper oil level
- Worn or damaged slide metal

SR908000

**INSTABLE HANDLING
INSTABLE HANDLING****Handlebars**

- Improperly installed or bent
- Loose handlebar tightening bolt

Steering

- Improperly installed handlebar crown
- Loose or overtightening steering nut
- Bent under bracket
- Improperly installed steering shaft (improperly tightened ring nut)
- Damaged bearing or ball race

Front forks

- Uneven oil levels on both sides
- Uneven spring tension
- Broken front fork spring
- Fatigued front fork spring
- Twisted front forks

Wheels

- Incorrect wheel balance
- Loose spooks
- Deformed wheel rim
- Unevenly worn tires
- Incorrect tire pressure
- Loose bearing
- Bent or loose wheel axle
- Excessive wheel runout

Frame

- Twisted
- Improperly installed bearing race
- Damaged head pipe bearings

Rear arm

- Faulty bearings
- Worm or damaged
- Faulty bushing
- Bent rear arm

Rear shock absorber

- Fatigued spring
- Improperly adjusted spring preload
- Oil leakage

Drive chain

- Improperly adjusted chain line

STARTER MOTOR DOES NOT OPERATE

TRBL
SHTG

?

A

SR*****

STARTER MOTOR DOES NOT OPERATE

STARTER MOTOR DOES NOT OPERATE

Battery

- Insufficient battery capacity
- Faulty battery

Fuse

- Burnt out, improper connection

Switch

- Faulty main switch
- Faulty starter switch
- Faulty clutch switch
- Faulty neutral switch
- Faulty neutral relay
- Faulty starter relay

Wireharness

- Loose battery terminal
- Loosely connected coupler
- Improperly grounded
- Broken wireharness

Starter motor

- Worn brush
- Faulty commutator
- Broken armature coil

Engine

- Faulty starter clutch
- Seized engine

VP909000

FAULTY SIGNAL AND LIGHTING SYSTEM**HEADLIGHT DARK**

- Improper bulb
- Too many electric accessories
- Hard charging
- Faulty rectifier/regulator
- Faulty battery
- Improperly connected coupler, connector, wireharness
- Improperly grounded
- Faulty main switch or Lights (dimmer) switch
- Bulb life expired

BULB BURNT OUT

- Improper bulb
- Faulty battery
- Faulty rectifier/regulator
- Improperly grounded
- Improperly mounting light unit
- Bulb life expired

FLASHER DOES NOT BLINK

- Improperly grounded
- Insufficient battery capacity
- Faulty fuse
- Faulty turn switch
- Faulty flasher relay
- Broken wireharness, incorrect coupler connection
- Bulb burnt out

FLASHER KEEPS ON

- Faulty flasher relay
- Insufficient battery capacity (nearly discharged)
- Bulb burnt out (front or rear)

FLASHER BLINKS SLOWER

- Faulty flasher relay
- Insufficient battery capacity (nearly discharged)
- Improper bulb
- Faulty main and/or turn switch

FLASHER BLINKS QUICKER

- Improper bulb
- Faulty flasher relay

HORN DOES NOT SOUND


- Faulty battery
- Faulty fuse
- Faulty main and/or horn switch
- Improper horn adjustment
- Faulty horn (burnt coil, connector)
- Broken wireharness

DC VOLTAGE FROM AUXILIARY DC TERMINAL DOES NOT PUT OUT

- Faulty battery
- Faulty fuse
- Faulty main switch
- Faulty auxiliary DC terminal (rusty socket or connector)
- Broken wireharness

M-6

AG200F '97 WIRING DIAGRAM



- ① CDI magneto
- ② Rectifier/Regulator
- ③ Starter relay
- ④ Battery
- ⑤ Fuse
- ⑥ Starting motor
- ⑦ Main switch
- ⑧ Neutral relay
- ⑨ CDI unit
- ⑩ Ignition coil
- ⑪ Spark plug
- ⑫ Clutch switch
- ⑬ Handlebar switches (right)
- ⑭ Start switch
- ⑮ Engine stop switch
- ⑯ Fuse (auxiliary DC terminal)
- ⑰ Auxiliary DC terminal socket
- ⑱ Speedometer
- ⑲ Meter light
- ⑳ Neutral indicator light
- ㉑ Neutral switch
- ㉒ Rear brake switch
- ㉓ Front brake switch
- ㉔ Tail/Brake light
- ㉕ Flasher relay
- ㉖ Turn switch
- ㉗ Flasher lights
- ㉘ Dimmer switch
- ㉙ Headlight
- ㉚ Lights switch
- ㉛ Horn switch
- ㉜ Horn
- ㉝ Handlebar switches (left)

COLOR CODE

BBlack	B/YBlack/Yellow	R/WRed/White
BrBrown	Br/WBrown/White	W/LWhite/Blue
ChChocolate	G/WGreen/White	W/RWhite/Red
DgDark green	G/LGreen/Blue		
GGreen	L/WBlue/White		
LBlue	L/YBlue/Yellow		
OOrange	Y/RYellow/Red		